

5. MAIN Electrical Parts List

[SM-A600FN]

Parts Code	Design LOC	Description
0202-002125	R5011,R6033,R7001	PB-SHORT-0603
0202-002125	R7007,R7014	PB-SHORT-0603
0401-001110	D5002	DIODE
0404-001972	D5003	DIODE
0406-001506	ZD7006,ZD7007	DIODE
0406-001561	ZD5015,ZD5016,ZD6002	DIODE
0406-001561	ZD6004,ZD6005,ZD6006	DIODE
0406-001561	ZD6015	DIODE
0406-001592	ZD5003,ZD6016,ZD6017	DIODE
0406-001592	ZD6019,ZD6020,ZD6021	DIODE
0406-001592	ZD6022,ZD6023,ZD6024	DIODE
0406-001659	ZD3000,ZD3001	DIODE
0406-001743	ZD5005,ZD5006,ZD5007	DIODE
0406-001743	ZD5008,ZD5009,ZD5010	DIODE
0406-001763	D5001,D5004,D5005	DIODE
0406-001763	D5006	DIODE
0406-001781	ZD6008,ZD6009,ZD6013	DIODE
0406-001787	ZD6001,ZD6003	DIODE
0406-001789	ZD5012	DIODE
0406-001797	ZD5001,ZD5002,ZD6012	DIODE
0406-001807	ZD2000,ZD3002,ZD5000	DIODE
0406-001807	ZD5017,ZD6007,ZD7013	DIODE
0406-001808	D5000	DIODE
0505-003618	Q5001	FET
0601-003547	LED5001	LED;RM435GA
0601-003667	LED5000	LED;RM435GA
1001-001835	U3001	IC
1001-001911	U1011	IC
1001-001974	U1005	IC
1001-001999	U1001	IC
1001-002022	U1006,U1010,U2010	IC
1009-001070	U7007	IC
1105-002784	UCP400UP	IC
1107-002552	UME5000	IC
1201-003786	U3005	IC
1201-003974	U7029	IC
1201-003976	U1000	IC

5. MAIN Electrical Parts List

1201-004029	U7023	IC
1201-004109	PAM2000	IC
1201-004129	U2001	IC
1201-004178	U6000	IC
1203-008468	U5002	IC
1203-008693	U1004	IC
1203-008696	U7011	IC
1203-008719	U6004	IC
1203-008767	U5001	IC
1203-008865	U7003	IC
1203-008867	U3010	IC
1203-008870	U7005	IC
1203-008925	U7006	IC
1203-008951	U5005	IC
1203-008955	U7002,U7004	IC
1203-008989	U7000	IC
1203-008995	U5000	IC
1205-005565	UCP400	IC
1205-005767	U2003	IC
1205-005814	U3009	IC
1205-005929	U3007	IC
1209-002413	U7008	IC
1209-002450	U7009	IC
1209-002490	U7010	IC
1209-002556	U6001	IC
1404-001664	TH4000,TH4001	THERMISTOR
1404-001724	TH2000	THERMISTOR
1405-001395	V2000,VR1002,VR2001	VARISTOR
1405-001395	VR2003,VR2004	VARISTOR
1405-001403	V1001,V1002,V1003	VARISTOR
1405-001403	V1004,VR1001	VARISTOR
1405-001404	VR7000,VR7001	VARISTOR
1405-001410	VR1006	VARISTOR
1405-001411	V1007,V1008	VARISTOR
1405-001412	V1005,V1006	VARISTOR
1405-001425	V2001,V2002,V2003	VARISTOR
1405-001425	VR1005,VR2000,VR2005	VARISTOR
1405-001425	VR2006,VR3002	VARISTOR
1405-001431	V3001,VR1004	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1405-001450	V1009,VR1000	VARISTOR
2007-000141	R4019	R-CHIP
2007-002796	R6017,R6020	R-CHIP
2007-003015	R5057,R5058	R-CHIP
2007-007100	R1004	R-CHIP
2007-007190	R6008,R6009	R-CHIP
2007-007405	R1006	R-CHIP
2007-007741	R4000,R4003,R4005	R-CHIP
2007-007741	R4007,R4023,R4038	R-CHIP
2007-007741	R5000,R5027,R5052	R-CHIP
2007-007741	R5059,R6006,R7012	R-CHIP
2007-007798	R5023,TH5000	R-CHIP
2007-007942	R5049	R-CHIP
2007-008043	R2003	R-CHIP
2007-008056	R1005,R1012	R-CHIP
2007-008210	R5031	R-CHIP
2007-008785	R1013,R6016	R-CHIP
2007-008800	R4010,R4011,R4039	R-CHIP
2007-008800	R4040,R6019	R-CHIP
2007-008816	R6023	R-CHIP
2007-009111	R5002,R7011	R-CHIP
2007-009157	R2009,R4001,R4025	R-CHIP
2007-009157	R4027,R4033,R4034	R-CHIP
2007-009157	R5003,R5004,R5019	R-CHIP
2007-009157	R6010,R6011	R-CHIP
2007-009158	R5005	R-CHIP
2007-009171	R4024,R5001,R5018	R-CHIP
2007-009201	R6002,R6007	R-CHIP
2007-009212	R5008,R5010,R5056	R-CHIP
2007-009212	R6012	R-CHIP
2007-009314	R5014,R5037,R5038	R-CHIP
2007-009315	R5016,R5017,R5020	R-CHIP
2007-009315	R5022,R5040,R5041	R-CHIP
2007-009315	R5043,R5044,R5045	R-CHIP
2007-009352	R3020	R-CHIP
2007-009408	R4014,R4015,R4016	R-CHIP
2007-009408	R4017,R4018,R4020	R-CHIP
2007-009408	R4021,R4028,R4029	R-CHIP
2007-009408	R4030,R4031,R4032	R-CHIP

5. MAIN Electrical Parts List

2007-009408	R4035,R4048,R4049	R-CHIP
2007-009408	R6013,R6028,R6029	R-CHIP
2007-009408	R6030,R7008,R7009	R-CHIP
2007-009408	R7010	R-CHIP
2007-009793	R6022	R-CHIP
2007-009801	R5054	R-CHIP
2007-009805	R1008,R1010,R1018	R-CHIP
2007-009805	R1019,R1020,R1021	R-CHIP
2007-009805	R1024,R2000	R-CHIP
2007-009920	R4008,R4009,R4012	R-CHIP
2007-009969	R6015	R-CHIP
2007-010031	R6005	R-CHIP
2007-010202	R5025,R5026	R-CHIP
2007-010685	R6004	R-CHIP
2007-011043	R4013	R-CHIP
2007-012068	R5030	R-CHIP
2007-012202	R5053	R-CHIP
2203-000311	C3104	C-CERAMIC
2203-000812	C3109,C3127,C3141	C-CERAMIC
2203-000854	C3108,C3128	C-CERAMIC
2203-001153	C5101,C5148	C-CERAMIC
2203-005682	C2040,C3132,C5005	C-CERAMIC
2203-005682	C5093,C5094,C5095	C-CERAMIC
2203-005682	C5096,C5105,C5107	C-CERAMIC
2203-005682	C5124,C5156,C5159	C-CERAMIC
2203-005682	C5163,C6000,C7009	C-CERAMIC
2203-005719	C1016,C1039	C-CERAMIC
2203-005725	C3021	C-CERAMIC
2203-005727	C3038,C3039,C5103	C-CERAMIC
2203-005729	C6007,C6010,C7003	C-CERAMIC
2203-005729	C7007,C7008,C7096	C-CERAMIC
2203-005729	C7097,C7098,C7103	C-CERAMIC
2203-005729	C7104,C7105,C7106	C-CERAMIC
2203-005731	C2005,C2105,C6016	C-CERAMIC
2203-005731	C6017,L1013	C-CERAMIC
2203-005732	C5135,C6033,C6035	C-CERAMIC
2203-005734	C5162,C6001,C6014	C-CERAMIC
2203-005734	C6015	C-CERAMIC
2203-005736	C1004,C1005,C1006	C-CERAMIC

5. MAIN Electrical Parts List

2203-005736	C1007,C1014,C1015	C-CERAMIC
2203-005736	C1024,C1032,C1033	C-CERAMIC
2203-005736	C1037,C1041,C1043	C-CERAMIC
2203-005736	C1050,C1055,C1058	C-CERAMIC
2203-005736	C1059,C1128,C1130	C-CERAMIC
2203-005736	C1131,C1132,C1151	C-CERAMIC
2203-005736	C1244,C1247,C2000	C-CERAMIC
2203-005736	C2015,C2027,C2028	C-CERAMIC
2203-005736	C2047,C2048,C2049	C-CERAMIC
2203-005736	C2052,C2053,C2072	C-CERAMIC
2203-005736	C2073,C2098,C2100	C-CERAMIC
2203-005736	C2101,C2102,C2104	C-CERAMIC
2203-005736	C2106,C2108,C2114	C-CERAMIC
2203-005736	C2115,C2130,C2131	C-CERAMIC
2203-005736	C2133,C2134,C3011	C-CERAMIC
2203-005736	C3043,C3048,C3057	C-CERAMIC
2203-005736	C3131,C5051,C5161	C-CERAMIC
2203-005736	C6031,C7027,C7043	C-CERAMIC
2203-005736	C7048,L2052,L2057	C-CERAMIC
2203-005736	L3005,L3027,R1000	C-CERAMIC
2203-005777	C2059,C2062,C2094	C-CERAMIC
2203-005777	L1008,L2003,L2030	C-CERAMIC
2203-005789	C1045,C2001,C2034	C-CERAMIC
2203-005789	C2035,C2044,C2090	C-CERAMIC
2203-005789	C2296,C3050,L1009	C-CERAMIC
2203-005789	L1011	C-CERAMIC
2203-005792	C2013,C2112,C5114	C-CERAMIC
2203-005792	L2008	C-CERAMIC
2203-005806	C2003,C2007,C2021	C-CERAMIC
2203-005806	C2103	C-CERAMIC
2203-006048	C6009	C-CERAMIC
2203-006120	C6022	C-CERAMIC
2203-006187	L1023	C-CERAMIC
2203-006194	C2132,C5123,C5160	C-CERAMIC
2203-006194	C6020,C6023	C-CERAMIC
2203-006305	C2095,C2096,C2099	C-CERAMIC
2203-006305	C3012,C3037,C3045	C-CERAMIC
2203-006305	C3137,L2009,L2046	C-CERAMIC
2203-006318	C2031,C5115,L2013	C-CERAMIC

5. MAIN Electrical Parts List

2203-006399	C4001,C4012,C4016	C-CERAMIC
2203-006399	C4021,C4022,C4025	C-CERAMIC
2203-006399	C4062,C4071,C7004	C-CERAMIC
2203-006399	C7005	C-CERAMIC
2203-006400	C1000,C2016,C2215	C-CERAMIC
2203-006400	C2222,C3007,C3090	C-CERAMIC
2203-006400	C4027,C4070	C-CERAMIC
2203-006410	C2026,C2055,C2088	C-CERAMIC
2203-006423	C2011,C2283,C3004	C-CERAMIC
2203-006423	C3006,C3013,C3015	C-CERAMIC
2203-006423	C3018,C4068,C4069	C-CERAMIC
2203-006423	C5076,C5100,C5104	C-CERAMIC
2203-006423	C5113,C5125,C5157	C-CERAMIC
2203-006423	C5158,C6011,C6012	C-CERAMIC
2203-006423	C7025	C-CERAMIC
2203-006556	C2010,C2018,C2038	C-CERAMIC
2203-006556	C2039,C2058,C5130	C-CERAMIC
2203-006556	C5154,C5155,C6021	C-CERAMIC
2203-006556	C6025,C6027	C-CERAMIC
2203-006562	C2004,C4064,C4065	C-CERAMIC
2203-006562	C5042,C5043,C5121	C-CERAMIC
2203-006562	C6006,C6039,C7038	C-CERAMIC
2203-006562	C7042	C-CERAMIC
2203-006611	C2009,C5132,L1044	C-CERAMIC
2203-006642	C2228	C-CERAMIC
2203-006648	C6024	C-CERAMIC
2203-006665	C2042,C3066	C-CERAMIC
2203-006668	C2123,C2231,C4032	C-CERAMIC
2203-006668	C5097,C5098	C-CERAMIC
2203-006707	C3047,C3049,C3051	C-CERAMIC
2203-006707	C3052,C3056	C-CERAMIC
2203-006839	C2017,C5068,C5069	C-CERAMIC
2203-006839	C5071,C7049,C7050	C-CERAMIC
2203-006841	C5110,C5134	C-CERAMIC
2203-006872	C7099	C-CERAMIC
2203-006896	C6002,C6013	C-CERAMIC
2203-006979	C2076,C2078,C2085	C-CERAMIC
2203-006979	C2286,C2288,C2290	C-CERAMIC
2203-006979	C2292,C2295,C3143	C-CERAMIC

5. MAIN Electrical Parts List

2203-006979	C3145,C6019,R6034	C-CERAMIC
2203-007210	C3019,C3025,C3026	C-CERAMIC
2203-007210	C5141,C5142,C6040	C-CERAMIC
2203-007210	C6042	C-CERAMIC
2203-007240	C5080,C5084,C5086	C-CERAMIC
2203-007240	C5087,C5151,C5153	C-CERAMIC
2203-007269	C7028,C7032,C7033	C-CERAMIC
2203-007269	C7044,C7047	C-CERAMIC
2203-007271	C2006,C2012,C5013	C-CERAMIC
2203-007271	C5092,C5099,C5109	C-CERAMIC
2203-007271	C5117	C-CERAMIC
2203-007279	C2020,C5074,C7031	C-CERAMIC
2203-007317	C3009,C3028,C3088	C-CERAMIC
2203-007317	C3089,C4020,C4030	C-CERAMIC
2203-007317	C5024,C5025,C7026	C-CERAMIC
2203-007317	C7046,C7075	C-CERAMIC
2203-007391	C2282,C3020,C6005	C-CERAMIC
2203-007393	C1100,C5062,C5070	C-CERAMIC
2203-007393	C5081,C5082,C5150	C-CERAMIC
2203-007393	C7035	C-CERAMIC
2203-007544	C6004	C-CERAMIC
2203-007775	C5053	C-CERAMIC
2203-007796	C1099,C2075,C2284	C-CERAMIC
2203-007796	C2289,C2293,C3005	C-CERAMIC
2203-007796	C3022,C3027,C3077	C-CERAMIC
2203-007796	C3085,C3087,C4000	C-CERAMIC
2203-007796	C4002,C4003,C4006	C-CERAMIC
2203-007796	C4007,C4008,C4009	C-CERAMIC
2203-007796	C4010,C4011,C4013	C-CERAMIC
2203-007796	C4015,C4017,C4019	C-CERAMIC
2203-007796	C4023,C4024,C4026	C-CERAMIC
2203-007796	C4033,C4034,C4035	C-CERAMIC
2203-007796	C4037,C4038,C4040	C-CERAMIC
2203-007796	C4043,C4046,C4047	C-CERAMIC
2203-007796	C4048,C4049,C4050	C-CERAMIC
2203-007796	C4051,C4052,C4053	C-CERAMIC
2203-007796	C4057,C4060,C4061	C-CERAMIC
2203-007796	C4063,C5006,C5007	C-CERAMIC
2203-007796	C5008,C5009,C5010	C-CERAMIC

5. MAIN Electrical Parts List

2203-007796	C5016,C5017,C5018	C-CERAMIC
2203-007796	C5019,C5020,C5022	C-CERAMIC
2203-007796	C5028,C5034,C5035	C-CERAMIC
2203-007796	C5036,C5037,C5038	C-CERAMIC
2203-007796	C5040,C5073,C5079	C-CERAMIC
2203-007796	C5088,C5089,C5090	C-CERAMIC
2203-007796	C5091,C5118,C5144	C-CERAMIC
2203-007796	C7006,C7011,C7013	C-CERAMIC
2203-007796	C7014,C7015,C7017	C-CERAMIC
2203-007796	C7018,C7019,C7021	C-CERAMIC
2203-007796	C7023,C7040,C7041	C-CERAMIC
2203-008094	C6028	C-CERAMIC
2203-008097	C2019,C6029	C-CERAMIC
2203-008161	C5004	C-CERAMIC
2203-008242	C3031,C3135,C4028	C-CERAMIC
2203-008242	C4041,C4044,C4056	C-CERAMIC
2203-008242	C4059,C5039	C-CERAMIC
2203-008529	C3030,C5000,C5001	C-CERAMIC
2203-008529	C5059,C5063,C5064	C-CERAMIC
2203-008529	C5065,C6008,C6043	C-CERAMIC
2203-008572	C5054,C5136	C-CERAMIC
2203-008654	C5149	C-CERAMIC
2203-008860	C3084,C3086,C5083	C-CERAMIC
2203-008860	C7010,C7016,C7020	C-CERAMIC
2203-008860	C7022	C-CERAMIC
2203-008876	C3008,C5106,C6036	C-CERAMIC
2203-008876	C6038,C7039	C-CERAMIC
2203-009210	C3064,C3130	C-CERAMIC
2203-009444	C6026	C-CERAMIC
2203-009551	C6032	C-CERAMIC
2203-009733	C1098,C2077,C2287	C-CERAMIC
2203-009733	C2291,C2294,C3080	C-CERAMIC
2203-009733	C4036,C4042,C4055	C-CERAMIC
2203-009733	C7001,C7045,C7074	C-CERAMIC
2203-009736	C3032,C4014,C4018	C-CERAMIC
2203-009736	C5023,C5112,C5143	C-CERAMIC
2203-009736	C5152	C-CERAMIC
2203-009858	C5041,C5066	C-CERAMIC
2203-009917	C6003	C-CERAMIC

5. MAIN Electrical Parts List

2703-002309	L6008	INDUCTOR
2703-002649	C1062,C2024,L2007	INDUCTOR
2703-002900	L5008	INDUCTOR
2703-002901	L1025	INDUCTOR
2703-002907	L2034,L3020	INDUCTOR
2703-002953	C1009,L5009	INDUCTOR
2703-002958	L1005,L1006,L1034	INDUCTOR
2703-002959	L1021,L1045,L1048	INDUCTOR
2703-002959	L3035,U7031	INDUCTOR
2703-002999	C1042	INDUCTOR
2703-003878	L6012	INDUCTOR
2703-004000	L2051	INDUCTOR
2703-004001	C1025	INDUCTOR
2703-004012	C1003,L2005,L2010	INDUCTOR
2703-004012	L2011,L2020,L2058	INDUCTOR
2703-004013	C2091,L2022,L2029	INDUCTOR
2703-004013	L2048,L2070,L3030	INDUCTOR
2703-004018	C1023,C2030,L1015	INDUCTOR
2703-004018	L1017,L2016,L2032	INDUCTOR
2703-004018	L3031,L3037	INDUCTOR
2703-004032	C1017,L1014	INDUCTOR
2703-004034	C2113,L1019,L1035	INDUCTOR
2703-004034	L3015	INDUCTOR
2703-004036	L2078	INDUCTOR
2703-004037	L1018,L2000	INDUCTOR
2703-004038	C1002,C1021,C1051	INDUCTOR
2703-004038	C2084,C2097,L1003	INDUCTOR
2703-004038	L1007,L1041,L2043	INDUCTOR
2703-004038	L2053,L3029	INDUCTOR
2703-004286	C1061,L1004,L2002	INDUCTOR
2703-004286	L2024,L2044,L2050	INDUCTOR
2703-004286	L2056,L2065,L3033	INDUCTOR
2703-004288	L3032	INDUCTOR
2703-004289	L3016	INDUCTOR
2703-004301	C2029,C2087,C2129	INDUCTOR
2703-004328	L2006,L2012,L2017	INDUCTOR
2703-004328	L2036,L2049,L2054	INDUCTOR
2703-004363	C2014	INDUCTOR
2703-004367	L1020	INDUCTOR

5. MAIN Electrical Parts List

2703-004369	L3013	INDUCTOR
2703-004763	L1001,L1032,L1043	INDUCTOR
2703-004853	C1030,L1002,L2074	INDUCTOR
2703-004901	L5002,L5003,L5004	INDUCTOR
2703-004901	L5005,L5006	INDUCTOR
2703-005066	L1033	INDUCTOR
2703-005085	C1008,C2041,C2046	INDUCTOR
2703-005085	C3041,L1029,L1030	INDUCTOR
2703-005085	L2001,L2023,L2047	INDUCTOR
2703-005085	L2077	INDUCTOR
2703-005087	C2093,L1012,L2045	INDUCTOR
2703-005087	L2066,L2067	INDUCTOR
2703-005109	L5011	INDUCTOR
2703-005117	L7007,L7008	INDUCTOR
2703-005118	L7006	INDUCTOR
2703-005200	L3006	INDUCTOR
2703-005296	C2022,L1024	INDUCTOR
2703-005372	L3018,L3019	INDUCTOR
2703-005505	L6001	INDUCTOR
2801-005487	OSC3000	CRYSTAL
2801-005496	OSC5000	CRYSTAL
2805-001106	OSC3001	OSCILLATOR
2809-001419	TCX2000	OSCILLATOR
2901-001798	F7005,F7006,F7007	FILTER
2901-001798	F7008,F7009	FILTER
2904-002143	F2002	FILTER
2904-002257	F2007	FILTER
2904-002266	F1002	FILTER
2904-002319	F2010	FILTER
2904-002339	F2006	FILTER
2904-002349	F2005	FILTER
2904-002350	F2003	FILTER
2904-002355	F3003,F3004	FILTER
2904-002390	F3000	FILTER
2910-000401	F2001	FILTER
2911-000435	U2005	FILTER
2911-000447	U1003	FILTER
3301-001438	L3036	CORE-FERRITE BEAD
3301-001778	R1028	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-001885	L6000,L6014,L6016	CORE-FERRITE BEAD
3301-002078	L6006,L6007,L6009	CORE-FERRITE BEAD
3301-002078	L6010,L6013,L7003	CORE-FERRITE BEAD
3301-002078	L7012,R6018	CORE-FERRITE BEAD
3301-002122	L1031,L1230,L2069	CORE-FERRITE BEAD
3301-002122	L6002,L6004	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7013	CORE-FERRITE BEAD
3301-002223	L7014	CORE-FERRITE BEAD
3301-002236	L5015,L6003,L6005	CORE-FERRITE BEAD
3301-002236	L6015	CORE-FERRITE BEAD
3301-002237	L1000,L1042,L2073	CORE-FERRITE BEAD
3301-002237	L3000	CORE-FERRITE BEAD
3301-002238	L2039,L2042,L3007	CORE-FERRITE BEAD
3301-002238	L3009	CORE-FERRITE BEAD
3301-002240	L2059,L2061	CORE-FERRITE BEAD
3301-002241	R7005	CORE-FERRITE BEAD
3301-002254	L5000,L5007	CORE-FERRITE BEAD
3301-002287	L5014	CORE-FERRITE BEAD
3301-002304	R7013	CORE-FERRITE BEAD
3301-002312	L2037,L2040,L2060	CORE-FERRITE BEAD
3301-002312	L2062,L4000,L7005	CORE-FERRITE BEAD
3301-002312	L7009,L7010	CORE-FERRITE BEAD
3301-002335	L6011	CORE-FERRITE BEAD
3705-001708	CON1000,CON1006	CONNECTOR
3709-001880	CN5000	CONNECTOR
3709-001891	CN5001	CONNECTOR
3711-007107	HEA7001	CONNECTOR
3711-007810	HEA6000	CONNECTOR
3711-008182	HEA7000	CONNECTOR
3711-008508	HEA7002	CONNECTOR
3711-008847	HDC5001	CONNECTOR
3712-001604	ANT3003,ANT3004	CONNECTOR
3712-001621	ANT6004,ANT6005	CONNECTOR
3712-001621	ANT6006,ANT6007	CONNECTOR
3712-001621	ANT6008,ANT6009	CONNECTOR
3712-001621	ANT6010,ANT6011	CONNECTOR
3712-001621	ANT6012,CON5001	CONNECTOR
3712-001621	CON5002,CON5003	CONNECTOR
3712-001634	ANT5004,ANT5006	CONNECTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3712-001666	ANT6002,ANT6003	CONNECTOR
3712-001694	ANT1010,ANT1011	CONNECTOR
3712-001694	ANT1012,ANT1015	CONNECTOR
3712-001694	ANT1016,ANT2002	CONNECTOR
3712-001694	ANT5003,ANT5007	CONNECTOR
3712-001694	ANT6000,ANT6001	CONNECTOR
3712-001749	ANT1002,ANT1003	CONNECTOR
3712-001749	ANT1004,ANT1005	CONNECTOR
3712-001749	ANT1007,ANT1008	CONNECTOR
3712-001749	ANT1009,ANT2001	CONNECTOR
3712-001749	ANT2004,ANT2006	CONNECTOR
3712-001749	ANT2007,ANT2008	CONNECTOR
3712-001749	ANT2010,ANT3005	CONNECTOR
3712-001749	ANT3006	CONNECTOR
3712-001800	ANT1000,ANT1013	CONNECTOR
3712-001800	ANT1018,ANT1020	CONNECTOR
3722-003954	IFC5000	JACK-PHONE
4709-002196	F2009	RF-MODULE
4709-002351	F3001	RF-MODULE
4709-002464	F1000	RF-MODULE
4709-002484	F2004	RF-MODULE
4709-002589	F1001,F1004	RF-MODULE
GH61-04484A	SUS7000	SUS
GH61-08266A	SUS7001	SUS
GH62-00044A	CN7000,CN7001	CONTACT
GH63-14633A	SC7003	SHIELDCAN
GH63-15417A	SC7006	SHIELDCAN
GH63-15418A	SC7007	SHIELDCAN
GH63-15419A	SC7008	SHIELDCAN
GH63-15420A	SC7004	SHIELDCAN
GH63-15421A	SC7002	SHIELDCAN
GH63-15422A	SC7005	SHIELDCAN
GH02-16501A	SC7006SP	TAPE

5. MAIN Electrical Parts List

[SM-A600F]

Parts Code	Design Loc	Description
0202-002125	R5012,R6033,R7000	PB-SHORT-0603
0202-002125	R7007,R7016	PB-SHORT-0603
0401-001110	D5002	DIODE-SWITCHING
0404-001972	D5003	DIODE-SCHOTTKY
0406-001506	ZD7006,ZD7007	DIODE-TVS
0406-001561	ZD5015,ZD5016,ZD6002	DIODE-TVS
0406-001561	ZD6004,ZD6005,ZD6006	DIODE-TVS
0406-001561	ZD6015	DIODE-TVS
0406-001592	ZD5003,ZD6016,ZD6017	DIODE-TVS
0406-001592	ZD6019,ZD6020,ZD6021	DIODE-TVS
0406-001592	ZD6022,ZD6023,ZD6024	DIODE-TVS
0406-001743	ZD5005,ZD5006,ZD5007	DIODE-TVS
0406-001743	ZD5008,ZD5009,ZD5010	DIODE-TVS
0406-001763	D5001,D5004,D5005	DIODE-TVS
0406-001763	D5006	DIODE-TVS
0406-001781	ZD6008,ZD6009,ZD6013	DIODE-TVS
0406-001787	ZD6001,ZD6003	DIODE-TVS
0406-001789	ZD5012	DIODE-TVS
0406-001797	ZD5001,ZD5002,ZD6012	DIODE-TVS
0406-001807	ZD2000,ZD3002,ZD5000	DIODE-TVS
0406-001807	ZD5017,ZD6007,ZD7013	DIODE-TVS
0406-001808	D5000	DIODE-TVS
0505-003618	Q5001	FET-SILICON
0601-003547	LED5001	LED
0601-003667	LED5000	LED
1001-001835	U3001	IC
1001-001911	U1011	IC
1001-001974	U1005	IC
1001-001999	U1001	IC
1001-002022	U1006,U1010,U2010	IC
1009-001070	U7007	IC
1105-002927	UCP400UP	IC
1107-002609	UME5000	IC
1201-003786	U3005	IC
1201-003974	U7029	IC
1201-003976	U1000	IC
1201-004029	U7023	IC

5. MAIN Electrical Parts List

1201-004109	PAM2000	IC
1201-004129	U2001	IC
1201-004178	U6000	IC
1203-008468	U5002	IC
1203-008693	U1004	IC
1203-008696	U7011	IC
1203-008719	U6004	IC
1203-008767	U5001	IC
1203-008865	U7003	IC
1203-008870	U7005	IC
1203-008925	U7006	IC
1203-008951	U5005	IC
1203-008955	U7002,U7004	IC
1203-008989	U7000	IC
1203-008995	U5000	IC
1205-005565	UCP400	IC
1205-005767	U2003	IC
1205-005929	U3007	IC
1209-002413	U7008	IC
1209-002450	U7009	IC
1209-002490	U7010	IC
1209-002556	U6001	IC
1404-001664	TH4000,TH4001	THERMISTOR
1404-001724	TH2000	THERMISTOR
1405-001395	V2000,VR1002,VR2001	VARISTOR
1405-001395	VR2003,VR2004	VARISTOR
1405-001403	V1001,V1002,V1003	VARISTOR
1405-001403	V1004,VR1001	VARISTOR
1405-001404	VR7000,VR7001	VARISTOR
1405-001410	VR1006	VARISTOR
1405-001411	V1007,V1008	VARISTOR
1405-001412	V1005,V1006	VARISTOR
1405-001425	V2001,V2002,V2003	VARISTOR
1405-001425	VR1005,VR2000,VR2005	VARISTOR
1405-001425	VR2006,VR3002	VARISTOR
1405-001431	V3001,VR1004	VARISTOR
1405-001450	V1009,VR1000	VARISTOR
2007-000141	R4019	R-CHIP
2007-002796	R6017,R6020	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-003015	R5057,R5058	R-CHIP
2007-007100	R1004	R-CHIP
2007-007190	R6008,R6009	R-CHIP
2007-007405	R1006	R-CHIP
2007-007741	R4000,R4003,R4005	R-CHIP
2007-007741	R4007,R4023,R4038	R-CHIP
2007-007741	R5000,R5027,R5052	R-CHIP
2007-007741	R5059,R6006,R7012	R-CHIP
2007-007798	R5023,TH5000	R-CHIP
2007-007942	R5049	R-CHIP
2007-008043	R2003	R-CHIP
2007-008056	R1005,R1012	R-CHIP
2007-008210	R5031	R-CHIP
2007-008785	R1013,R6016	R-CHIP
2007-008800	R4010,R4011,R4039	R-CHIP
2007-008800	R4040,R6019	R-CHIP
2007-008816	R6023	R-CHIP
2007-009111	R5002,R7011	R-CHIP
2007-009157	R2009,R4001,R4026	R-CHIP
2007-009157	R4027,R4033,R4034	R-CHIP
2007-009157	R5003,R5004,R5019	R-CHIP
2007-009157	R6010,R6011	R-CHIP
2007-009158	R5005	R-CHIP
2007-009171	R4024,R5001,R5018	R-CHIP
2007-009201	R6002,R6007	R-CHIP
2007-009212	R5008,R5010,R5056	R-CHIP
2007-009212	R6012	R-CHIP
2007-009314	R5014,R5037,R5038	R-CHIP
2007-009315	R5016,R5017,R5020	R-CHIP
2007-009315	R5022,R5040,R5041	R-CHIP
2007-009315	R5043,R5044,R5045	R-CHIP
2007-009408	R4014,R4015,R4016	R-CHIP
2007-009408	R4017,R4018,R4020	R-CHIP
2007-009408	R4021,R4028,R4029	R-CHIP
2007-009408	R4030,R4031,R4032	R-CHIP
2007-009408	R4035,R4048,R4049	R-CHIP
2007-009408	R6013,R6028,R6029	R-CHIP
2007-009408	R6030,R7008,R7009	R-CHIP
2007-009408	R7010	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-009793	R6022	R-CHIP
2007-009801	R5054	R-CHIP
2007-009805	R1008,R1010,R1018	R-CHIP
2007-009805	R1019,R1020,R1021	R-CHIP
2007-009805	R1024,R2000	R-CHIP
2007-009920	R4008,R4009,R4012	R-CHIP
2007-009969	R6015	R-CHIP
2007-010031	R6005	R-CHIP
2007-010202	R5025,R5026	R-CHIP
2007-010685	R6004	R-CHIP
2007-011043	R4013	R-CHIP
2007-012068	R5030	R-CHIP
2007-012202	R5053	R-CHIP
2203-001153	C5101,C5148	C-CERAMIC,CHIP
2203-005682	C2040,C3132,C5005	C-CERAMIC,CHIP
2203-005682	C5093,C5094,C5095	C-CERAMIC,CHIP
2203-005682	C5096,C5105,C5107	C-CERAMIC,CHIP
2203-005682	C5124,C5156,C5159	C-CERAMIC,CHIP
2203-005682	C5163,C6000,C7009	C-CERAMIC,CHIP
2203-005719	C1016,C1039	C-CERAMIC,CHIP
2203-005725	C3021	C-CERAMIC,CHIP
2203-005727	C3038,C3039,C5103	C-CERAMIC,CHIP
2203-005729	C6007,C6010,C7003	C-CERAMIC,CHIP
2203-005729	C7007,C7008,C7096	C-CERAMIC,CHIP
2203-005729	C7097,C7098,C7103	C-CERAMIC,CHIP
2203-005729	C7104,C7105,C7106	C-CERAMIC,CHIP
2203-005731	C2005,C2105,C6016	C-CERAMIC,CHIP
2203-005731	C6017,L1013	C-CERAMIC,CHIP
2203-005732	C5135,C6033,C6035	C-CERAMIC,CHIP
2203-005734	C5162,C6001,C6014	C-CERAMIC,CHIP
2203-005734	C6015	C-CERAMIC,CHIP
2203-005736	C1004,C1005,C1006	C-CERAMIC,CHIP
2203-005736	C1007,C1014,C1015	C-CERAMIC,CHIP
2203-005736	C1024,C1032,C1033	C-CERAMIC,CHIP
2203-005736	C1037,C1041,C1043	C-CERAMIC,CHIP
2203-005736	C1050,C1055,C1058	C-CERAMIC,CHIP
2203-005736	C1059,C1128,C1130	C-CERAMIC,CHIP
2203-005736	C1131,C1132,C1151	C-CERAMIC,CHIP
2203-005736	C1244,C1247,C2000	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C2015,C2027,C2028	C-CERAMIC,CHIP
2203-005736	C2047,C2048,C2049	C-CERAMIC,CHIP
2203-005736	C2052,C2053,C2072	C-CERAMIC,CHIP
2203-005736	C2073,C2098,C2100	C-CERAMIC,CHIP
2203-005736	C2101,C2102,C2104	C-CERAMIC,CHIP
2203-005736	C2106,C2108,C2114	C-CERAMIC,CHIP
2203-005736	C2115,C2130,C2131	C-CERAMIC,CHIP
2203-005736	C2133,C2134,C3011	C-CERAMIC,CHIP
2203-005736	C3043,C3048,C3057	C-CERAMIC,CHIP
2203-005736	C3131,C5051,C5161	C-CERAMIC,CHIP
2203-005736	C6031,C7027,C7043	C-CERAMIC,CHIP
2203-005736	C7048,L2052,L2057	C-CERAMIC,CHIP
2203-005736	L3005,L3027,R1000	C-CERAMIC,CHIP
2203-005777	C2059,C2062,C2094	C-CERAMIC,CHIP
2203-005777	L1008,L2003,L2030	C-CERAMIC,CHIP
2203-005789	C1045,C2001,C2034	C-CERAMIC,CHIP
2203-005789	C2035,C2044,C2090	C-CERAMIC,CHIP
2203-005789	C2296,C3050,L1009	C-CERAMIC,CHIP
2203-005789	L1011	C-CERAMIC,CHIP
2203-005792	C2013,C2112,C5114	C-CERAMIC,CHIP
2203-005792	L2008	C-CERAMIC,CHIP
2203-005806	C2003,C2007,C2021	C-CERAMIC,CHIP
2203-005806	C2103	C-CERAMIC,CHIP
2203-006048	C6009	C-CERAMIC,CHIP
2203-006120	C6022	C-CERAMIC,CHIP
2203-006187	L1023	C-CERAMIC,CHIP
2203-006194	C2132,C5123,C5160	C-CERAMIC,CHIP
2203-006194	C6020,C6023	C-CERAMIC,CHIP
2203-006305	C2095,C2096,C2099	C-CERAMIC,CHIP
2203-006305	C3012,C3037,C3045	C-CERAMIC,CHIP
2203-006305	C3137,L2009,L2046	C-CERAMIC,CHIP
2203-006318	C2031,C5115,L2013	C-CERAMIC,CHIP
2203-006399	C4001,C4012,C4016	C-CERAMIC,CHIP
2203-006399	C4021,C4022,C4025	C-CERAMIC,CHIP
2203-006399	C4062,C4071,C7004	C-CERAMIC,CHIP
2203-006399	C7005	C-CERAMIC,CHIP
2203-006400	C1000,C2016,C2215	C-CERAMIC,CHIP
2203-006400	C2222,C3007,C4027	C-CERAMIC,CHIP
2203-006400	C4070	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006410	C2026,C2055,C2088	C-CERAMIC,CHIP
2203-006423	C2011,C2283,C3004	C-CERAMIC,CHIP
2203-006423	C3006,C3013,C3015	C-CERAMIC,CHIP
2203-006423	C3018,C4068,C4069	C-CERAMIC,CHIP
2203-006423	C5076,C5100,C5104	C-CERAMIC,CHIP
2203-006423	C5113,C5125,C5157	C-CERAMIC,CHIP
2203-006423	C5158,C6011,C6012	C-CERAMIC,CHIP
2203-006423	C7025	C-CERAMIC,CHIP
2203-006556	C2010,C2018,C2038	C-CERAMIC,CHIP
2203-006556	C2039,C2058,C5130	C-CERAMIC,CHIP
2203-006556	C5154,C5155,C6021	C-CERAMIC,CHIP
2203-006556	C6025,C6027	C-CERAMIC,CHIP
2203-006562	C2004,C4064,C4065	C-CERAMIC,CHIP
2203-006562	C5042,C5043,C5121	C-CERAMIC,CHIP
2203-006562	C6006,C6039,C7038	C-CERAMIC,CHIP
2203-006562	C7042	C-CERAMIC,CHIP
2203-006611	C2009,C5132,L1044	C-CERAMIC,CHIP
2203-006642	C2228	C-CERAMIC,CHIP
2203-006648	C6024	C-CERAMIC,CHIP
2203-006665	C2042,C3066	C-CERAMIC,CHIP
2203-006668	C2123,C2231,C4032	C-CERAMIC,CHIP
2203-006668	C5097,C5098	C-CERAMIC,CHIP
2203-006707	C3047,C3049,C3051	C-CERAMIC,CHIP
2203-006707	C3052,C3056	C-CERAMIC,CHIP
2203-006839	C2017,C5068,C5069	C-CERAMIC,CHIP
2203-006839	C5071,C7049,C7050	C-CERAMIC,CHIP
2203-006841	C5110,C5134	C-CERAMIC,CHIP
2203-006872	C7099	C-CERAMIC,CHIP
2203-006896	C6002,C6013	C-CERAMIC,CHIP
2203-006979	C2076,C2078,C2085	C-CERAMIC,CHIP
2203-006979	C2286,C2288,C2290	C-CERAMIC,CHIP
2203-006979	C2292,C2295,C3143	C-CERAMIC,CHIP
2203-006979	C3145,C6019,R6034	C-CERAMIC,CHIP
2203-007210	C3019,C3025,C3026	C-CERAMIC,CHIP
2203-007210	C5141,C5142,C6040	C-CERAMIC,CHIP
2203-007210	C6042	C-CERAMIC,CHIP
2203-007240	C5080,C5084,C5086	C-CERAMIC,CHIP
2203-007240	C5087,C5151,C5153	C-CERAMIC,CHIP
2203-007269	C7028,C7032,C7033	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007269	C7044,C7047	C-CERAMIC,CHIP
2203-007271	C2006,C2012,C5013	C-CERAMIC,CHIP
2203-007271	C5092,C5099,C5109	C-CERAMIC,CHIP
2203-007271	C5117	C-CERAMIC,CHIP
2203-007279	C2020,C5074,C7031	C-CERAMIC,CHIP
2203-007317	C3009,C3028,C4020	C-CERAMIC,CHIP
2203-007317	C4030,C5024,C5025	C-CERAMIC,CHIP
2203-007317	C7026,C7046,C7075	C-CERAMIC,CHIP
2203-007391	C2282,C3020,C6005	C-CERAMIC,CHIP
2203-007393	C1100,C5062,C5070	C-CERAMIC,CHIP
2203-007393	C5081,C5082,C5150	C-CERAMIC,CHIP
2203-007393	C7035	C-CERAMIC,CHIP
2203-007544	C6004	C-CERAMIC,CHIP
2203-007775	C5053	C-CERAMIC,CHIP
2203-007796	C1099,C2075,C2284	C-CERAMIC,CHIP
2203-007796	C2289,C2293,C3005	C-CERAMIC,CHIP
2203-007796	C3022,C3027,C4000	C-CERAMIC,CHIP
2203-007796	C4002,C4003,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4010,C4011,C4013	C-CERAMIC,CHIP
2203-007796	C4015,C4017,C4019	C-CERAMIC,CHIP
2203-007796	C4023,C4024,C4026	C-CERAMIC,CHIP
2203-007796	C4033,C4034,C4035	C-CERAMIC,CHIP
2203-007796	C4037,C4038,C4040	C-CERAMIC,CHIP
2203-007796	C4043,C4046,C4047	C-CERAMIC,CHIP
2203-007796	C4048,C4049,C4050	C-CERAMIC,CHIP
2203-007796	C4051,C4052,C4053	C-CERAMIC,CHIP
2203-007796	C4057,C4060,C4061	C-CERAMIC,CHIP
2203-007796	C4063,C5006,C5007	C-CERAMIC,CHIP
2203-007796	C5008,C5009,C5010	C-CERAMIC,CHIP
2203-007796	C5016,C5017,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5020,C5022	C-CERAMIC,CHIP
2203-007796	C5028,C5034,C5035	C-CERAMIC,CHIP
2203-007796	C5036,C5037,C5038	C-CERAMIC,CHIP
2203-007796	C5040,C5073,C5079	C-CERAMIC,CHIP
2203-007796	C5088,C5089,C5090	C-CERAMIC,CHIP
2203-007796	C5091,C5118,C5144	C-CERAMIC,CHIP
2203-007796	C7006,C7011,C7013	C-CERAMIC,CHIP
2203-007796	C7014,C7015,C7017	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C7018,C7019,C7021	C-CERAMIC,CHIP
2203-007796	C7023,C7040,C7041	C-CERAMIC,CHIP
2203-008094	C6028	C-CERAMIC,CHIP
2203-008097	C2019,C6029	C-CERAMIC,CHIP
2203-008161	C5004	C-CERAMIC,CHIP
2203-008242	C3031,C3135,C4028	C-CERAMIC,CHIP
2203-008242	C4041,C4044,C4056	C-CERAMIC,CHIP
2203-008242	C4059,C5039	C-CERAMIC,CHIP
2203-008529	C3030,C5000,C5001	C-CERAMIC,CHIP
2203-008529	C5059,C5063,C5064	C-CERAMIC,CHIP
2203-008529	C5065,C6008,C6043	C-CERAMIC,CHIP
2203-008572	C5054,C5136	C-CERAMIC,CHIP
2203-008654	C5149	C-CERAMIC,CHIP
2203-008860	C5083,C7010,C7016	C-CERAMIC,CHIP
2203-008860	C7020,C7022	C-CERAMIC,CHIP
2203-008876	C3008,C5106,C6036	C-CERAMIC,CHIP
2203-008876	C6038,C7039	C-CERAMIC,CHIP
2203-009444	C6026	C-CERAMIC,CHIP
2203-009551	C6032	C-CERAMIC,CHIP
2203-009733	C1098,C2077,C2287	C-CERAMIC,CHIP
2203-009733	C2291,C2294,C4036	C-CERAMIC,CHIP
2203-009733	C4042,C4055,C7001	C-CERAMIC,CHIP
2203-009733	C7045,C7074	C-CERAMIC,CHIP
2203-009736	C3032,C4014,C4018	C-CERAMIC,CHIP
2203-009736	C5023,C5112,C5143	C-CERAMIC,CHIP
2203-009736	C5152	C-CERAMIC,CHIP
2203-009858	C5041,C5066	C-CERAMIC,CHIP
2203-009917	C6003	C-CERAMIC,CHIP
2703-002309	L6008	INDUCTOR-SMD
2703-002649	C1062,C2024,L2007	INDUCTOR-SMD
2703-002900	L5008	INDUCTOR-SMD
2703-002901	L1025	INDUCTOR-SMD
2703-002907	L2034,L3020	INDUCTOR-SMD
2703-002953	C1009,L5009	INDUCTOR-SMD
2703-002958	L1005,L1006,L1034	INDUCTOR-SMD
2703-002959	L1021,L1045,L1048	INDUCTOR-SMD
2703-002959	L3035,U7031	INDUCTOR-SMD
2703-002999	C1042	INDUCTOR-SMD
2703-003878	L6012	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004000	L2051	INDUCTOR-SMD
2703-004001	C1025	INDUCTOR-SMD
2703-004012	C1003,L2005,L2010	INDUCTOR-SMD
2703-004012	L2011,L2020,L2058	INDUCTOR-SMD
2703-004013	C2091,L2022,L2029	INDUCTOR-SMD
2703-004013	L2048,L2070,L3030	INDUCTOR-SMD
2703-004018	C1023,C2030,L1015	INDUCTOR-SMD
2703-004018	L1017,L2016,L2032	INDUCTOR-SMD
2703-004018	L3031,L3037	INDUCTOR-SMD
2703-004032	C1017,L1014	INDUCTOR-SMD
2703-004034	C2113,L1019,L1035	INDUCTOR-SMD
2703-004034	L3015	INDUCTOR-SMD
2703-004036	L2078	INDUCTOR-SMD
2703-004037	L1018,L2000	INDUCTOR-SMD
2703-004038	C1002,C1021,C1051	INDUCTOR-SMD
2703-004038	C2084,C2097,L1003	INDUCTOR-SMD
2703-004038	L1007,L1041,L2043	INDUCTOR-SMD
2703-004038	L2053,L3029	INDUCTOR-SMD
2703-004286	C1061,L1004,L2002	INDUCTOR-SMD
2703-004286	L2024,L2044,L2050	INDUCTOR-SMD
2703-004286	L2056,L2065,L3033	INDUCTOR-SMD
2703-004288	L3032	INDUCTOR-SMD
2703-004289	L3016	INDUCTOR-SMD
2703-004301	C2029,C2087,C2129	INDUCTOR-SMD
2703-004328	L2006,L2012,L2017	INDUCTOR-SMD
2703-004328	L2036,L2049,L2054	INDUCTOR-SMD
2703-004363	C2014	INDUCTOR-SMD
2703-004367	L1020	INDUCTOR-SMD
2703-004369	L3013	INDUCTOR-SMD
2703-004763	L1001,L1032,L1043	INDUCTOR-SMD
2703-004853	C1030,L1002,L2074	INDUCTOR-SMD
2703-004901	L5002,L5003,L5004	INDUCTOR-SMD
2703-004901	L5005,L5006	INDUCTOR-SMD
2703-005066	L1033	INDUCTOR-SMD
2703-005085	C1008,C2041,C2046	INDUCTOR-SMD
2703-005085	C3041,L1029,L1030	INDUCTOR-SMD
2703-005085	L2001,L2023,L2047	INDUCTOR-SMD
2703-005085	L2077	INDUCTOR-SMD
2703-005087	C2093,L1012,L2045	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-005087	L2066,L2067	INDUCTOR-SMD
2703-005109	L5011	INDUCTOR-SMD
2703-005117	L7007,L7008	INDUCTOR-SMD
2703-005118	L7006	INDUCTOR-SMD
2703-005200	L3006	INDUCTOR-SMD
2703-005296	C2022,L1024	INDUCTOR-SMD
2703-005505	L6001	INDUCTOR-SMD
2801-005487	OSC3000	CRYSTAL-UNIT
2801-005496	OSC5000	CRYSTAL-UNIT
2805-001106	OSC3001	OSCILLATOR
2809-001419	TCX2000	OSCILLATOR
2901-001798	F7005,F7006,F7007	FILTER-EMI SMD
2901-001798	F7008,F7009	FILTER-EMI SMD
2904-002143	F2002	FILTER-SAW
2904-002257	F2007	FILTER-SAW
2904-002266	F1002	FILTER-SAW
2904-002319	F2010	FILTER-SAW
2904-002339	F2006	FILTER-SAW
2904-002349	F2005	FILTER-SAW
2904-002350	F2003	FILTER-SAW
2904-002355	F3003,F3004	FILTER-SAW
2904-002390	F3000	FILTER-SAW
2910-000401	F2001	FILTER
2911-000435	U2005	FILTER
2911-000447	U1003	FILTER
3301-001438	L3036	CORE-FERRITE BEAD
3301-001778	R1028	CORE-FERRITE BEAD
3301-001885	L6000,L6014,L6016	CORE-FERRITE BEAD
3301-002078	L6006,L6007,L6009	CORE-FERRITE BEAD
3301-002078	L6010,L6013,L7003	CORE-FERRITE BEAD
3301-002078	L7012,R6018	CORE-FERRITE BEAD
3301-002122	L1031,L1230,L2069	CORE-FERRITE BEAD
3301-002122	L6002,L6004	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7013	CORE-FERRITE BEAD
3301-002223	L7014	CORE-FERRITE BEAD
3301-002236	L5015,L6003,L6005	CORE-FERRITE BEAD
3301-002236	L6015	CORE-FERRITE BEAD
3301-002237	L1000,L1042,L2073	CORE-FERRITE BEAD
3301-002237	L3000	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002238	L2039,L2042,L3007	CORE-FERRITE BEAD
3301-002238	L3009	CORE-FERRITE BEAD
3301-002240	L2059,L2061	CORE-FERRITE BEAD
3301-002241	R7005	CORE-FERRITE BEAD
3301-002254	L5000,L5007	CORE-FERRITE BEAD
3301-002287	L5014	CORE-FERRITE BEAD
3301-002304	R7013	CORE-FERRITE BEAD
3301-002312	L2037,L2040,L2060	CORE-FERRITE BEAD
3301-002312	L2062,L4000,L7005	CORE-FERRITE BEAD
3301-002312	L7009,L7010	CORE-FERRITE BEAD
3301-002335	L6011	CORE-FERRITE BEAD
3705-001708	CON1000,CON1006	CONNECTOR-COAXIAL
3709-001880	CN5000	CONNECTOR-CARD EDGE
3709-001891	CN5001	CONNECTOR-CARD EDGE
3711-007107	HEA7001	CONNECTOR-HEADER
3711-007810	HEA6000	CONNECTOR-HEADER
3711-008182	HEA7000	CONNECTOR-HEADER
3711-008508	HEA7002	CONNECTOR-HEADER
3711-008847	HDC5001	CONNECTOR-HEADER
3712-001621	ANT6004,ANT6005	CONNECTOR
3712-001621	ANT6006,ANT6007	CONNECTOR
3712-001621	ANT6008,ANT6009	CONNECTOR
3712-001621	ANT6010,ANT6011	CONNECTOR
3712-001621	ANT6012,CON5001	CONNECTOR
3712-001621	CON5002,CON5003	CONNECTOR
3712-001634	ANT5004,ANT5006	CONNECTOR
3712-001666	ANT6002,ANT6003	CONNECTOR
3712-001694	ANT1010,ANT1011	CONNECTOR
3712-001694	ANT1012,ANT1015	CONNECTOR
3712-001694	ANT1016,ANT2002	CONNECTOR
3712-001694	ANT5003,ANT5007	CONNECTOR
3712-001694	ANT6000,ANT6001	CONNECTOR
3712-001749	ANT1002,ANT1003	CONNECTOR
3712-001749	ANT1004,ANT1005	CONNECTOR
3712-001749	ANT1007,ANT1008	CONNECTOR
3712-001749	ANT1009,ANT2001	CONNECTOR
3712-001749	ANT2004,ANT2006	CONNECTOR
3712-001749	ANT2007,ANT2008	CONNECTOR
3712-001749	ANT2010,ANT3005	CONNECTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3712-001749	ANT3006	CONNECTOR
3712-001800	ANT1000,ANT1013	CONNECTOR
3712-001800	ANT1018,ANT1020	CONNECTOR
3722-003954	IFC5000	JACK-PHONE
4709-002196	F2009	RF-MODULE
4709-002351	F3001	RF-MODULE
4709-002464	F1000	RF-MODULE
4709-002484	F2004	RF-MODULE
4709-002589	F1001,F1004	RF-MODULE
GH61-04484A	SUS7000	SHIELD CAN
GH61-08266A	SUS7001	SHIELD CAN
GH62-00044A	CN7000,CN7001	SHIELD CAN
GH63-14633A	SC7003	SHIELD CAN
GH63-15417A	SC7006	SHIELD CAN
GH63-15418A	SC7007	SHIELD CAN
GH63-15419A	SC7008	SHIELD CAN
GH63-15420A	SC7004	SHIELD CAN
GH63-15421A	SC7002	SHIELD CAN
GH63-15422A	SC7005	SHIELD CAN
GH02-16501A	SC7004SP	TAPE

5. MAIN Electrical Parts List

[SM-A600GN]

Parts Code	Design Loc	Description
0202-002125	R5011,R6033,R7003	PB-SHORT-0603
0202-002125	R7007,R7014	PB-SHORT-0603
0401-001110	D5002	DIODE-SWITCHING
0404-001972	D5003	DIODE-SCHOTTKY
0406-001506	ZD7006,ZD7007	DIODE-TVS
0406-001561	ZD5015,ZD5016,ZD6002	DIODE-TVS
0406-001561	ZD6004,ZD6005,ZD6006	DIODE-TVS
0406-001561	ZD6015	DIODE-TVS
0406-001592	ZD5003,ZD6016,ZD6017	DIODE-TVS
0406-001592	ZD6019,ZD6020,ZD6021	DIODE-TVS
0406-001592	ZD6022,ZD6023,ZD6024	DIODE-TVS
0406-001659	ZD3000,ZD3001	DIODE-TVS
0406-001743	ZD5005,ZD5006,ZD5007	DIODE-TVS
0406-001743	ZD5008,ZD5009,ZD5010	DIODE-TVS
0406-001763	D5001,D5004,D5005	DIODE-TVS
0406-001763	D5006	DIODE-TVS
0406-001781	ZD6008,ZD6009,ZD6013	DIODE-TVS
0406-001787	ZD6001,ZD6003	DIODE-TVS
0406-001789	ZD5012	DIODE-TVS
0406-001797	ZD5001,ZD5002,ZD6012	DIODE-TVS
0406-001807	ZD2000,ZD3002,ZD5000	DIODE-TVS
0406-001807	ZD5017,ZD6007,ZD7013	DIODE-TVS
0406-001808	D5000	DIODE-TVS
0505-003618	Q5001	FET-SILICON
0601-003547	LED5001	LED
0601-003667	LED5000	LED
1001-001835	U3001	IC
1001-001844	U2000	IC
1001-001911	U1011	IC
1001-001974	U1005	IC
1001-001999	U1001	IC
1001-002022	U1006,U1010,U2010	IC
1009-001070	U7007	IC
1105-002784	UCP400UP	IC
1107-002552	UME5000	IC
1201-003786	U3005	IC
1201-003974	U7029	IC

5. MAIN Electrical Parts List

1201-003976	U1000	IC
1201-004029	U7023	IC
1201-004109	PAM2000	IC
1201-004129	U2001	IC
1201-004178	U6000	IC
1203-008468	U5002	IC
1203-008693	U1004	IC
1203-008696	U7011	IC
1203-008719	U6004	IC
1203-008767	U5001	IC
1203-008865	U7003	IC
1203-008867	U3010	IC
1203-008870	U7005	IC
1203-008925	U7006	IC
1203-008951	U5005	IC
1203-008955	U7002,U7004	IC
1203-008989	U7000	IC
1203-008995	U5000	IC
1205-005565	UCP400	IC
1205-005767	U2003	IC
1205-005814	U3009	IC
1205-005929	U3007	IC
1209-002413	U7008	IC
1209-002450	U7009	IC
1209-002490	U7010	IC
1209-002556	U6001	IC
1404-001664	TH4000,TH4001	THERMISTOR
1404-001724	TH2000	THERMISTOR
1405-001395	V2000,VR1002,VR2001	VARISTOR
1405-001395	VR2003,VR2004	VARISTOR
1405-001403	V1001,V1002,V1003	VARISTOR
1405-001403	V1004,VR1001	VARISTOR
1405-001404	VR7000,VR7001	VARISTOR
1405-001410	VR1006	VARISTOR
1405-001411	V1007,V1008	VARISTOR
1405-001412	V1005,V1006	VARISTOR
1405-001416	V1012	VARISTOR
1405-001425	V2001,V2002,V2003	VARISTOR
1405-001425	VR1005,VR2000,VR2005	VARISTOR

5. MAIN Electrical Parts List

1405-001425	VR2006,VR3002	VARISTOR
1405-001431	V3001,VR1004	VARISTOR
1405-001450	V1009	VARISTOR
2007-000141	R4019	R-CHIP
2007-002796	R6017,R6020	R-CHIP
2007-003015	R5057,R5058	R-CHIP
2007-007100	R1004	R-CHIP
2007-007190	R6008,R6009	R-CHIP
2007-007405	R1006	R-CHIP
2007-007741	R4000,R4003,R4005	R-CHIP
2007-007741	R4007,R4023,R4038	R-CHIP
2007-007741	R5000,R5027,R5052	R-CHIP
2007-007741	R5059,R6006,R7012	R-CHIP
2007-007798	R5023,TH5000	R-CHIP
2007-007942	R5049	R-CHIP
2007-008043	R2003	R-CHIP
2007-008056	R1005,R1012	R-CHIP
2007-008210	R5031	R-CHIP
2007-008785	R1013,R6016	R-CHIP
2007-008800	R4010,R4011,R4039	R-CHIP
2007-008800	R4040,R6019	R-CHIP
2007-008816	R6023	R-CHIP
2007-009111	R5002,R7011	R-CHIP
2007-009157	R2009,R4001,R4025	R-CHIP
2007-009157	R4027,R4033,R4034	R-CHIP
2007-009157	R5003,R5004,R5019	R-CHIP
2007-009157	R6010,R6011	R-CHIP
2007-009158	R5005	R-CHIP
2007-009171	R4024,R5001,R5018	R-CHIP
2007-009201	R6002,R6007	R-CHIP
2007-009212	R5008,R5010,R5056	R-CHIP
2007-009212	R6012	R-CHIP
2007-009314	R5014,R5037,R5038	R-CHIP
2007-009315	R5016,R5017,R5020	R-CHIP
2007-009315	R5022,R5040,R5041	R-CHIP
2007-009315	R5043,R5044,R5045	R-CHIP
2007-009352	R3020	R-CHIP
2007-009408	R4014,R4015,R4016	R-CHIP
2007-009408	R4017,R4018,R4020	R-CHIP

5. MAIN Electrical Parts List

2007-009408	R4021,R4028,R4029	R-CHIP
2007-009408	R4030,R4031,R4032	R-CHIP
2007-009408	R4035,R4048,R4049	R-CHIP
2007-009408	R6013,R6028,R6029	R-CHIP
2007-009408	R6030,R7008,R7009	R-CHIP
2007-009408	R7010	R-CHIP
2007-009793	R6022	R-CHIP
2007-009801	R5054	R-CHIP
2007-009805	R1008,R1010,R1018	R-CHIP
2007-009805	R1019,R1020,R1021	R-CHIP
2007-009805	R1024,R2000	R-CHIP
2007-009920	R4008,R4009,R4012	R-CHIP
2007-009969	R6015	R-CHIP
2007-010031	R6005	R-CHIP
2007-010202	R5025,R5026	R-CHIP
2007-010685	R6004	R-CHIP
2007-011043	R4013	R-CHIP
2007-012068	R5030	R-CHIP
2007-012202	R5053	R-CHIP
2203-000311	C3104	C-CERAMIC,CHIP
2203-000812	C3109,C3127,C3141	C-CERAMIC,CHIP
2203-000854	C3108,C3128	C-CERAMIC,CHIP
2203-001153	C5101,C5148	C-CERAMIC,CHIP
2203-005682	C2040,C3132,C5005	C-CERAMIC,CHIP
2203-005682	C5093,C5094,C5095	C-CERAMIC,CHIP
2203-005682	C5096,C5105,C5107	C-CERAMIC,CHIP
2203-005682	C5124,C5156,C5159	C-CERAMIC,CHIP
2203-005682	C5163,C6000,C7009	C-CERAMIC,CHIP
2203-005717	C1058	C-CERAMIC,CHIP
2203-005719	C1016,C1039	C-CERAMIC,CHIP
2203-005725	C3021	C-CERAMIC,CHIP
2203-005727	C3038,C3039,C5103	C-CERAMIC,CHIP
2203-005729	C1083,C6007,C6010	C-CERAMIC,CHIP
2203-005729	C7003,C7007,C7008	C-CERAMIC,CHIP
2203-005729	C7096,C7097,C7098	C-CERAMIC,CHIP
2203-005729	C7103,C7104,C7105	C-CERAMIC,CHIP
2203-005729	C7106	C-CERAMIC,CHIP
2203-005731	C2005,C2105,C6016	C-CERAMIC,CHIP
2203-005731	C6017,L1013	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005732	C1036,C5135,C6033	C-CERAMIC,CHIP
2203-005732	C6035	C-CERAMIC,CHIP
2203-005734	C5162,C6001,C6014	C-CERAMIC,CHIP
2203-005734	C6015	C-CERAMIC,CHIP
2203-005736	C1004,C1005,C1006	C-CERAMIC,CHIP
2203-005736	C1007,C1014,C1015	C-CERAMIC,CHIP
2203-005736	C1024,C1032,C1033	C-CERAMIC,CHIP
2203-005736	C1037,C1041,C1043	C-CERAMIC,CHIP
2203-005736	C1048,C1050,C1055	C-CERAMIC,CHIP
2203-005736	C1059,C1063,C1128	C-CERAMIC,CHIP
2203-005736	C1130,C1131,C1132	C-CERAMIC,CHIP
2203-005736	C1151,C1244,C1247	C-CERAMIC,CHIP
2203-005736	C2000,C2015,C2027	C-CERAMIC,CHIP
2203-005736	C2028,C2049,C2052	C-CERAMIC,CHIP
2203-005736	C2053,C2067,C2072	C-CERAMIC,CHIP
2203-005736	C2073,C2098,C2100	C-CERAMIC,CHIP
2203-005736	C2101,C2102,C2104	C-CERAMIC,CHIP
2203-005736	C2106,C2108,C2114	C-CERAMIC,CHIP
2203-005736	C2115,C2119,C2120	C-CERAMIC,CHIP
2203-005736	C2121,C2130,C2131	C-CERAMIC,CHIP
2203-005736	C2133,C2134,C3011	C-CERAMIC,CHIP
2203-005736	C3043,C3048,C3057	C-CERAMIC,CHIP
2203-005736	C3131,C5051,C5161	C-CERAMIC,CHIP
2203-005736	C6031,C7027,C7043	C-CERAMIC,CHIP
2203-005736	C7048,L2052,L2057	C-CERAMIC,CHIP
2203-005736	L3005,L3027,R1000	C-CERAMIC,CHIP
2203-005777	C2059,C2062,C2066	C-CERAMIC,CHIP
2203-005777	C2094,L1008,L2003	C-CERAMIC,CHIP
2203-005777	L2030	C-CERAMIC,CHIP
2203-005789	C1045,C2001,C2024	C-CERAMIC,CHIP
2203-005789	C2034,C2035,C2036	C-CERAMIC,CHIP
2203-005789	C2044,C2090,C2248	C-CERAMIC,CHIP
2203-005789	C2296,C3050,L1009	C-CERAMIC,CHIP
2203-005789	L1011,L2014	C-CERAMIC,CHIP
2203-005792	C1064,C1065,C2013	C-CERAMIC,CHIP
2203-005792	C2112,C5114,L2008	C-CERAMIC,CHIP
2203-005806	C2003,C2007,C2021	C-CERAMIC,CHIP
2203-005806	C2103	C-CERAMIC,CHIP
2203-006048	C6009	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006120	C6022	C-CERAMIC,CHIP
2203-006187	L1023	C-CERAMIC,CHIP
2203-006194	C2132,C5123,C5160	C-CERAMIC,CHIP
2203-006194	C6020,C6023	C-CERAMIC,CHIP
2203-006305	C2095,C2096,C2099	C-CERAMIC,CHIP
2203-006305	C3012,C3037,C3045	C-CERAMIC,CHIP
2203-006305	C3137,L2009,L2046	C-CERAMIC,CHIP
2203-006305	L3032	C-CERAMIC,CHIP
2203-006318	C2031,C5115,L3024	C-CERAMIC,CHIP
2203-006399	C4001,C4012,C4016	C-CERAMIC,CHIP
2203-006399	C4021,C4022,C4025	C-CERAMIC,CHIP
2203-006399	C4062,C4071,C7004	C-CERAMIC,CHIP
2203-006399	C7005	C-CERAMIC,CHIP
2203-006400	C1000,C1073,C1077	C-CERAMIC,CHIP
2203-006400	C2016,C2215,C2222	C-CERAMIC,CHIP
2203-006400	C3007,C3090,C4027	C-CERAMIC,CHIP
2203-006400	C4070	C-CERAMIC,CHIP
2203-006410	C2026,C2055,C2088	C-CERAMIC,CHIP
2203-006423	C2011,C2283,C3004	C-CERAMIC,CHIP
2203-006423	C3006,C3013,C3015	C-CERAMIC,CHIP
2203-006423	C3018,C4068,C4069	C-CERAMIC,CHIP
2203-006423	C5076,C5100,C5104	C-CERAMIC,CHIP
2203-006423	C5113,C5125,C5157	C-CERAMIC,CHIP
2203-006423	C5158,C6011,C6012	C-CERAMIC,CHIP
2203-006423	C7025	C-CERAMIC,CHIP
2203-006556	C2010,C2018,C2038	C-CERAMIC,CHIP
2203-006556	C2039,C2058,C5130	C-CERAMIC,CHIP
2203-006556	C5154,C5155,C6021	C-CERAMIC,CHIP
2203-006556	C6025,C6027	C-CERAMIC,CHIP
2203-006562	C2004,C4064,C4065	C-CERAMIC,CHIP
2203-006562	C5042,C5043,C5121	C-CERAMIC,CHIP
2203-006562	C6006,C6039,C7038	C-CERAMIC,CHIP
2203-006562	C7042	C-CERAMIC,CHIP
2203-006611	C2009,C5132,L1044	C-CERAMIC,CHIP
2203-006642	C2228	C-CERAMIC,CHIP
2203-006648	C6024	C-CERAMIC,CHIP
2203-006665	C2042,C3066	C-CERAMIC,CHIP
2203-006668	C2123,C2231,C4032	C-CERAMIC,CHIP
2203-006668	C5097,C5098	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006707	C3047,C3049,C3051	C-CERAMIC,CHIP
2203-006707	C3052,C3056	C-CERAMIC,CHIP
2203-006839	C2017,C5068,C5069	C-CERAMIC,CHIP
2203-006839	C5071,C7049,C7050	C-CERAMIC,CHIP
2203-006841	C5110,C5134	C-CERAMIC,CHIP
2203-006872	C7099	C-CERAMIC,CHIP
2203-006896	C6002,C6013	C-CERAMIC,CHIP
2203-006979	C2076,C2078,C2085	C-CERAMIC,CHIP
2203-006979	C2286,C2288,C2290	C-CERAMIC,CHIP
2203-006979	C2292,C2295,C3143	C-CERAMIC,CHIP
2203-006979	C3145,C6019,R6034	C-CERAMIC,CHIP
2203-007194	C3053	C-CERAMIC,CHIP
2203-007210	C3019,C3025,C3026	C-CERAMIC,CHIP
2203-007210	C5141,C5142,C6040	C-CERAMIC,CHIP
2203-007210	C6042	C-CERAMIC,CHIP
2203-007240	C5080,C5084,C5086	C-CERAMIC,CHIP
2203-007240	C5087,C5151,C5153	C-CERAMIC,CHIP
2203-007269	C7028,C7032,C7033	C-CERAMIC,CHIP
2203-007269	C7044,C7047	C-CERAMIC,CHIP
2203-007271	C2006,C2012,C5013	C-CERAMIC,CHIP
2203-007271	C5092,C5099,C5109	C-CERAMIC,CHIP
2203-007271	C5117	C-CERAMIC,CHIP
2203-007279	C2020,C5074,C7031	C-CERAMIC,CHIP
2203-007317	C3009,C3028,C3088	C-CERAMIC,CHIP
2203-007317	C3089,C4020,C4030	C-CERAMIC,CHIP
2203-007317	C5024,C5025,C7026	C-CERAMIC,CHIP
2203-007317	C7046,C7075	C-CERAMIC,CHIP
2203-007391	C2282,C3020,C6005	C-CERAMIC,CHIP
2203-007393	C1100,C5062,C5070	C-CERAMIC,CHIP
2203-007393	C5081,C5082,C5150	C-CERAMIC,CHIP
2203-007393	C7035	C-CERAMIC,CHIP
2203-007544	C6004	C-CERAMIC,CHIP
2203-007775	C5053	C-CERAMIC,CHIP
2203-007796	C1099,C2075,C2284	C-CERAMIC,CHIP
2203-007796	C2289,C2293,C3005	C-CERAMIC,CHIP
2203-007796	C3022,C3027,C3077	C-CERAMIC,CHIP
2203-007796	C3085,C3087,C4000	C-CERAMIC,CHIP
2203-007796	C4002,C4003,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C4010,C4011,C4013	C-CERAMIC,CHIP
2203-007796	C4015,C4017,C4019	C-CERAMIC,CHIP
2203-007796	C4023,C4024,C4026	C-CERAMIC,CHIP
2203-007796	C4033,C4034,C4035	C-CERAMIC,CHIP
2203-007796	C4037,C4038,C4040	C-CERAMIC,CHIP
2203-007796	C4043,C4046,C4047	C-CERAMIC,CHIP
2203-007796	C4048,C4049,C4050	C-CERAMIC,CHIP
2203-007796	C4051,C4052,C4053	C-CERAMIC,CHIP
2203-007796	C4057,C4060,C4061	C-CERAMIC,CHIP
2203-007796	C4063,C5006,C5007	C-CERAMIC,CHIP
2203-007796	C5008,C5009,C5010	C-CERAMIC,CHIP
2203-007796	C5016,C5017,C5018	C-CERAMIC,CHIP
2203-007796	C5019,C5020,C5022	C-CERAMIC,CHIP
2203-007796	C5028,C5034,C5035	C-CERAMIC,CHIP
2203-007796	C5036,C5037,C5038	C-CERAMIC,CHIP
2203-007796	C5040,C5073,C5079	C-CERAMIC,CHIP
2203-007796	C5088,C5089,C5090	C-CERAMIC,CHIP
2203-007796	C5091,C5118,C5144	C-CERAMIC,CHIP
2203-007796	C7006,C7011,C7013	C-CERAMIC,CHIP
2203-007796	C7014,C7015,C7017	C-CERAMIC,CHIP
2203-007796	C7018,C7019,C7021	C-CERAMIC,CHIP
2203-007796	C7023,C7040,C7041	C-CERAMIC,CHIP
2203-008094	C6028	C-CERAMIC,CHIP
2203-008097	C2019,C6029	C-CERAMIC,CHIP
2203-008161	C5004	C-CERAMIC,CHIP
2203-008242	C3031,C3135,C4028	C-CERAMIC,CHIP
2203-008242	C4041,C4044,C4056	C-CERAMIC,CHIP
2203-008242	C4059,C5039	C-CERAMIC,CHIP
2203-008529	C3030,C5000,C5001	C-CERAMIC,CHIP
2203-008529	C5059,C5063,C5064	C-CERAMIC,CHIP
2203-008529	C5065,C6008,C6043	C-CERAMIC,CHIP
2203-008572	C5054,C5136	C-CERAMIC,CHIP
2203-008654	C5149	C-CERAMIC,CHIP
2203-008860	C3084,C3086,C5083	C-CERAMIC,CHIP
2203-008860	C7010,C7016,C7020	C-CERAMIC,CHIP
2203-008860	C7022	C-CERAMIC,CHIP
2203-008876	C3008,C5106,C6036	C-CERAMIC,CHIP
2203-008876	C6038,C7039	C-CERAMIC,CHIP
2203-009210	C3064,C3130	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-009444	C6026	C-CERAMIC,CHIP
2203-009551	C6032	C-CERAMIC,CHIP
2203-009733	C1098,C2077,C2287	C-CERAMIC,CHIP
2203-009733	C2291,C2294,C3080	C-CERAMIC,CHIP
2203-009733	C4036,C4042,C4055	C-CERAMIC,CHIP
2203-009733	C7001,C7045,C7074	C-CERAMIC,CHIP
2203-009736	C3032,C4014,C4018	C-CERAMIC,CHIP
2203-009736	C5023,C5112,C5143	C-CERAMIC,CHIP
2203-009736	C5152	C-CERAMIC,CHIP
2203-009858	C5041,C5066	C-CERAMIC,CHIP
2203-009917	C6003	C-CERAMIC,CHIP
2703-002309	L6008	INDUCTOR-SMD
2703-002649	C1062,L2007,L3025	INDUCTOR-SMD
2703-002858	L1027	INDUCTOR-SMD
2703-002900	L5008	INDUCTOR-SMD
2703-002901	L1022,L1025	INDUCTOR-SMD
2703-002907	L2034,L3020	INDUCTOR-SMD
2703-002951	C1074	INDUCTOR-SMD
2703-002953	C1009,C2122,L1071	INDUCTOR-SMD
2703-002953	L5009	INDUCTOR-SMD
2703-002955	L1037	INDUCTOR-SMD
2703-002958	L1005,L1006,L1034	INDUCTOR-SMD
2703-002958	L1077	INDUCTOR-SMD
2703-002959	L1021,L1045,L1048	INDUCTOR-SMD
2703-002959	L3035,U7031	INDUCTOR-SMD
2703-002999	C1042	INDUCTOR-SMD
2703-003878	L6012	INDUCTOR-SMD
2703-003970	L1124	INDUCTOR-SMD
2703-004000	L2051	INDUCTOR-SMD
2703-004001	C1025	INDUCTOR-SMD
2703-004012	C1003,C1066,L2005	INDUCTOR-SMD
2703-004012	L2010,L2011,L2020	INDUCTOR-SMD
2703-004012	L2058	INDUCTOR-SMD
2703-004013	C2091,L2022,L2029	INDUCTOR-SMD
2703-004013	L2048,L2070,L2071	INDUCTOR-SMD
2703-004013	L3030	INDUCTOR-SMD
2703-004018	C1023,C2030,L1015	INDUCTOR-SMD
2703-004018	L1017,L1068,L2016	INDUCTOR-SMD
2703-004018	L2032,L3031,L3037	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004032	C1017,L1014,L1049	INDUCTOR-SMD
2703-004034	C2113,L1019,L1035	INDUCTOR-SMD
2703-004034	L3015	INDUCTOR-SMD
2703-004035	L1047	INDUCTOR-SMD
2703-004036	L1046,L2078	INDUCTOR-SMD
2703-004037	L1018	INDUCTOR-SMD
2703-004038	C1002,C1021,C1051	INDUCTOR-SMD
2703-004038	C1061,C2084,C2097	INDUCTOR-SMD
2703-004038	L1003,L1007,L1041	INDUCTOR-SMD
2703-004038	L2043,L2053,L3029	INDUCTOR-SMD
2703-004286	L1004,L2002,L2021	INDUCTOR-SMD
2703-004286	L2024,L2028,L2044	INDUCTOR-SMD
2703-004286	L2050,L2056,L2065	INDUCTOR-SMD
2703-004286	L3033	INDUCTOR-SMD
2703-004289	L3016	INDUCTOR-SMD
2703-004301	C2029,C2087,C2129	INDUCTOR-SMD
2703-004328	L2006,L2012,L2017	INDUCTOR-SMD
2703-004328	L2036,L2041,L2049	INDUCTOR-SMD
2703-004328	L2054,L2063	INDUCTOR-SMD
2703-004363	C2014	INDUCTOR-SMD
2703-004367	L1020	INDUCTOR-SMD
2703-004369	L3013	INDUCTOR-SMD
2703-004763	L1001,L1028,L1032	INDUCTOR-SMD
2703-004763	L1043	INDUCTOR-SMD
2703-004764	C1071	INDUCTOR-SMD
2703-004853	C1030,L1002,L2074	INDUCTOR-SMD
2703-004901	L5002,L5003,L5004	INDUCTOR-SMD
2703-004901	L5005,L5006	INDUCTOR-SMD
2703-004911	L1038	INDUCTOR-SMD
2703-005066	L1033	INDUCTOR-SMD
2703-005085	C1008,C2041,C2046	INDUCTOR-SMD
2703-005085	C3041,L1029,L1030	INDUCTOR-SMD
2703-005085	L2001,L2023,L2047	INDUCTOR-SMD
2703-005085	L2077	INDUCTOR-SMD
2703-005087	C2093,C2136,L1012	INDUCTOR-SMD
2703-005087	L2000,L2045,L2066	INDUCTOR-SMD
2703-005087	L2067	INDUCTOR-SMD
2703-005109	L5011	INDUCTOR-SMD
2703-005117	L7007,L7008	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-005118	L7006	INDUCTOR-SMD
2703-005200	L3006	INDUCTOR-SMD
2703-005296	C2022,C2137,L1024	INDUCTOR-SMD
2703-005372	L3018,L3019	INDUCTOR-SMD
2703-005505	L6001	INDUCTOR-SMD
2801-005487	OSC3000	CRYSTAL-UNIT
2801-005496	OSC5000	CRYSTAL-UNIT
2805-001106	OSC3001	OSCILLATOR
2809-001419	TCX2000	OSCILLATOR-VCTCXO
2901-001798	F7005,F7006,F7007	FILTER-EMI SMD
2901-001798	F7008,F7009	FILTER-EMI SMD
2904-002143	F2002	FILTER-SAW
2904-002257	F2007	FILTER-SAW
2904-002266	F1002	FILTER-SAW
2904-002326	F2008	FILTER-SAW
2904-002339	F2006	FILTER-SAW
2904-002349	F2005	FILTER-SAW
2904-002350	F2003	FILTER-SAW
2904-002355	F3003,F3004	FILTER-SAW
2904-002365	F2000	FILTER-SAW
2904-002390	F3000	FILTER-SAW
2910-000364	F1007	FILTER
2910-000401	F2001	FILTER
2910-000402	U1007	FILTER
2911-000435	U2005	FILTER
2911-000447	U1003	FILTER
3301-001438	L3036	CORE-FERRITE BEAD
3301-001778	R1028	CORE-FERRITE BEAD
3301-001885	L6000,L6014,L6016	CORE-FERRITE BEAD
3301-002078	L6006,L6007,L6009	CORE-FERRITE BEAD
3301-002078	L6010,L6013,L7003	CORE-FERRITE BEAD
3301-002078	L7012,R6018	CORE-FERRITE BEAD
3301-002122	L1031,L1230,L2069	CORE-FERRITE BEAD
3301-002122	L6002,L6004	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7013	CORE-FERRITE BEAD
3301-002223	L7014	CORE-FERRITE BEAD
3301-002236	L5015,L6003,L6005	CORE-FERRITE BEAD
3301-002236	L6015	CORE-FERRITE BEAD
3301-002237	L1000,L1042,L2073	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002237	L3000	CORE-FERRITE BEAD
3301-002238	L2039,L2042,L3007	CORE-FERRITE BEAD
3301-002238	L3009	CORE-FERRITE BEAD
3301-002240	L2059,L2061	CORE-FERRITE BEAD
3301-002241	R7005	CORE-FERRITE BEAD
3301-002254	L5000,L5007	CORE-FERRITE BEAD
3301-002287	L5014	CORE-FERRITE BEAD
3301-002304	R7013	CORE-FERRITE BEAD
3301-002312	L2037,L2040,L2060	CORE-FERRITE BEAD
3301-002312	L2062,L4000,L7005	CORE-FERRITE BEAD
3301-002312	L7009,L7010	CORE-FERRITE BEAD
3301-002335	L6011	CORE-FERRITE BEAD
3705-001708	CON1000,CON1006	CONNECTOR-COAXIAL
3709-001880	CN5000	CONNECTOR-CARD EDGE
3709-001891	CN5001	CONNECTOR-CARD EDGE
3711-007107	HEA7001	CONNECTOR-HEADER
3711-007810	HEA6000	CONNECTOR-HEADER
3711-008182	HEA7000	CONNECTOR-HEADER
3711-008508	HEA7002	CONNECTOR-HEADER
3711-008847	HDC5001	CONNECTOR-HEADER
3712-001604	ANT3003,ANT3004	CONNECTOR
3712-001621	ANT6004,ANT6005	CONNECTOR
3712-001621	ANT6006,ANT6007	CONNECTOR
3712-001621	ANT6008,ANT6009	CONNECTOR
3712-001621	ANT6010,ANT6011	CONNECTOR
3712-001621	ANT6012,CON5001	CONNECTOR
3712-001621	CON5002,CON5003	CONNECTOR
3712-001634	ANT5004,ANT5006	CONNECTOR
3712-001666	ANT6002,ANT6003	CONNECTOR
3712-001694	ANT1010,ANT1011	CONNECTOR
3712-001694	ANT1012,ANT1015	CONNECTOR
3712-001694	ANT1016,ANT2002	CONNECTOR
3712-001694	ANT5003,ANT5007	CONNECTOR
3712-001694	ANT6000,ANT6001	CONNECTOR
3712-001749	ANT1002,ANT1003	CONNECTOR
3712-001749	ANT1004,ANT1005	CONNECTOR
3712-001749	ANT1007,ANT1008	CONNECTOR
3712-001749	ANT1009,ANT2001	CONNECTOR
3712-001749	ANT2004,ANT2006	CONNECTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3712-001749	ANT2007,ANT2008	CONNECTOR
3712-001749	ANT2010,ANT3005	CONNECTOR
3712-001749	ANT3006	CONNECTOR
3712-001800	ANT1000,ANT1013	CONNECTOR
3712-001800	ANT1018,ANT1020	CONNECTOR
3722-003954	IFC5000	JACK-PHONE
4709-002196	F2009	RF-MODULE
4709-002351	F3001	RF-MODULE
4709-002464	F1000	RF-MODULE
4709-002484	F2004	RF-MODULE
4709-002589	F1001,F1004	RF-MODULE
GH61-04484A	SUS7000	SHIELD CAN
GH61-08266A	SUS7001	SHIELD CAN
GH62-00044A	CN7000,CN7001	SHIELD CAN
GH63-14633A	SC7003	SHIELD CAN
GH63-15417A	SC7006	SHIELD CAN
GH63-15418A	SC7007	SHIELD CAN
GH63-15419A	SC7008	SHIELD CAN
GH63-15420A	SC7004	SHIELD CAN
GH63-15421A	SC7002	SHIELD CAN
GH63-15422A	SC7005	SHIELD CAN
GH02-16501A	SC7004SP	TAPE

5. MAIN Electrical Parts List

[SM-A600G]

Parts Code	Design Loc	Description
0202-002125	R5012,R6033,R7002	PB-SHORT-0603
0202-002125	R7007,R7014	PB-SHORT-0603
0401-001110	D5002	DIODE-SWITCHING
0404-001972	D5003	DIODE-SCHOTTKY
0406-001506	ZD7006,ZD7007	DIODE-TVS
0406-001561	ZD5015,ZD5016,ZD6002	DIODE-TVS
0406-001561	ZD6004,ZD6005,ZD6006	DIODE-TVS
0406-001561	ZD6015	DIODE-TVS
0406-001592	ZD5003,ZD6016,ZD6017	DIODE-TVS
0406-001592	ZD6019,ZD6020,ZD6021	DIODE-TVS
0406-001592	ZD6022,ZD6023,ZD6024	DIODE-TVS
0406-001743	ZD5005,ZD5006,ZD5007	DIODE-TVS
0406-001743	ZD5008,ZD5009,ZD5010	DIODE-TVS
0406-001763	D5001,D5004,D5005	DIODE-TVS
0406-001763	D5006	DIODE-TVS
0406-001781	ZD6008,ZD6009,ZD6013	DIODE-TVS
0406-001787	ZD6001,ZD6003	DIODE-TVS
0406-001789	ZD5012	DIODE-TVS
0406-001797	ZD5001,ZD5002,ZD6012	DIODE-TVS
0406-001807	ZD2000,ZD3002,ZD5000	DIODE-TVS
0406-001807	ZD5017,ZD6007,ZD7013	DIODE-TVS
0406-001808	D5000	DIODE-TVS
0505-003618	Q5001	FET-SILICON
0601-003547	LED5001	LED
0601-003667	LED5000	LED
1001-001835	U3001	IC
1001-001844	U2000	IC
1001-001911	U1011	IC
1001-001974	U1005	IC
1001-001999	U1001	IC
1001-002022	U1006,U1010,U2010	IC
1009-001070	U7007	IC
1105-002784	UCP400UP	IC
1107-002552	UME5000	IC
1201-003786	U3005	IC
1201-003974	U7029	IC
1201-003976	U1000	IC

5. MAIN Electrical Parts List

1201-004029	U7023	IC
1201-004109	PAM2000	IC
1201-004129	U2001	IC
1201-004178	U6000	IC
1203-008468	U5002	IC
1203-008693	U1004	IC
1203-008696	U7011	IC
1203-008719	U6004	IC
1203-008767	U5001	IC
1203-008865	U7003	IC
1203-008870	U7005	IC
1203-008925	U7006	IC
1203-008951	U5005	IC
1203-008955	U7002,U7004	IC
1203-008989	U7000	IC
1203-008995	U5000	IC
1205-005565	UCP400	IC
1205-005767	U2003	IC
1205-005929	U3007	IC
1209-002413	U7008	IC
1209-002450	U7009	IC
1209-002490	U7010	IC
1209-002556	U6001	IC
1404-001664	TH4000,TH4001	THERMISTOR
1404-001724	TH2000	THERMISTOR
1405-001395	V2000,VR1002,VR2001	VARISTOR
1405-001395	VR2003,VR2004	VARISTOR
1405-001403	V1001,V1002,V1003	VARISTOR
1405-001403	V1004,VR1001	VARISTOR
1405-001404	VR7000,VR7001	VARISTOR
1405-001410	VR1006	VARISTOR
1405-001411	V1007,V1008	VARISTOR
1405-001412	V1005,V1006	VARISTOR
1405-001416	V1012	VARISTOR
1405-001425	V2001,V2002,V2003	VARISTOR
1405-001425	VR1005,VR2000,VR2005	VARISTOR
1405-001425	VR2006,VR3002	VARISTOR
1405-001431	V3001,VR1004	VARISTOR
1405-001450	V1009	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-000141	R4019	R-CHIP
2007-002796	R6017,R6020	R-CHIP
2007-003015	R5057,R5058	R-CHIP
2007-007100	R1004	R-CHIP
2007-007190	R6008,R6009	R-CHIP
2007-007405	R1006	R-CHIP
2007-007741	R4000,R4003,R4005	R-CHIP
2007-007741	R4007,R4023,R4038	R-CHIP
2007-007741	R5000,R5027,R5052	R-CHIP
2007-007741	R5059,R6006,R7012	R-CHIP
2007-007798	R5023,TH5000	R-CHIP
2007-007942	R5049	R-CHIP
2007-008043	R2003	R-CHIP
2007-008056	R1005,R1012	R-CHIP
2007-008210	R5031	R-CHIP
2007-008785	R1013,R6016	R-CHIP
2007-008800	R4010,R4011,R4039	R-CHIP
2007-008800	R4040,R6019	R-CHIP
2007-008816	R6023	R-CHIP
2007-009111	R5002,R7011	R-CHIP
2007-009157	R2009,R4001,R4026	R-CHIP
2007-009157	R4027,R4033,R4034	R-CHIP
2007-009157	R5003,R5004,R5019	R-CHIP
2007-009157	R6010,R6011	R-CHIP
2007-009158	R5005	R-CHIP
2007-009171	R4024,R5001,R5018	R-CHIP
2007-009201	R6002,R6007	R-CHIP
2007-009212	R5008,R5010,R5056	R-CHIP
2007-009212	R6012	R-CHIP
2007-009314	R5014,R5037,R5038	R-CHIP
2007-009315	R5016,R5017,R5020	R-CHIP
2007-009315	R5022,R5040,R5041	R-CHIP
2007-009315	R5043,R5044,R5045	R-CHIP
2007-009408	R4014,R4015,R4016	R-CHIP
2007-009408	R4017,R4018,R4020	R-CHIP
2007-009408	R4021,R4028,R4029	R-CHIP
2007-009408	R4030,R4031,R4032	R-CHIP
2007-009408	R4035,R4048,R4049	R-CHIP
2007-009408	R6013,R6028,R6029	R-CHIP

5. MAIN Electrical Parts List

2007-009408	R6030,R7008,R7009	R-CHIP
2007-009408	R7010	R-CHIP
2007-009793	R6022	R-CHIP
2007-009801	R5054	R-CHIP
2007-009805	R1008,R1010,R1018	R-CHIP
2007-009805	R1019,R1020,R1021	R-CHIP
2007-009805	R1024,R2000	R-CHIP
2007-009920	R4008,R4009,R4012	R-CHIP
2007-009969	R6015	R-CHIP
2007-010031	R6005	R-CHIP
2007-010202	R5025,R5026	R-CHIP
2007-010685	R6004	R-CHIP
2007-011043	R4013	R-CHIP
2007-012068	R5030	R-CHIP
2007-012202	R5053	R-CHIP
2203-001153	C5101,C5148	C-CERAMIC,CHIP
2203-005682	C2040,C3132,C5005	C-CERAMIC,CHIP
2203-005682	C5093,C5094,C5095	C-CERAMIC,CHIP
2203-005682	C5096,C5105,C5107	C-CERAMIC,CHIP
2203-005682	C5124,C5156,C5159	C-CERAMIC,CHIP
2203-005682	C5163,C6000,C7009	C-CERAMIC,CHIP
2203-005717	C1058	C-CERAMIC,CHIP
2203-005719	C1016,C1039	C-CERAMIC,CHIP
2203-005725	C3021	C-CERAMIC,CHIP
2203-005727	C3038,C3039,C5103	C-CERAMIC,CHIP
2203-005729	C1083,C6007,C6010	C-CERAMIC,CHIP
2203-005729	C7003,C7007,C7008	C-CERAMIC,CHIP
2203-005729	C7096,C7097,C7098	C-CERAMIC,CHIP
2203-005729	C7103,C7104,C7105	C-CERAMIC,CHIP
2203-005729	C7106	C-CERAMIC,CHIP
2203-005731	C2005,C2105,C6016	C-CERAMIC,CHIP
2203-005731	C6017,L1013	C-CERAMIC,CHIP
2203-005732	C1036,C5135,C6033	C-CERAMIC,CHIP
2203-005732	C6035	C-CERAMIC,CHIP
2203-005734	C5162,C6001,C6014	C-CERAMIC,CHIP
2203-005734	C6015	C-CERAMIC,CHIP
2203-005736	C1004,C1005,C1006	C-CERAMIC,CHIP
2203-005736	C1007,C1014,C1015	C-CERAMIC,CHIP
2203-005736	C1024,C1032,C1033	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C1037,C1041,C1043	C-CERAMIC,CHIP
2203-005736	C1048,C1050,C1055	C-CERAMIC,CHIP
2203-005736	C1059,C1063,C1128	C-CERAMIC,CHIP
2203-005736	C1130,C1131,C1132	C-CERAMIC,CHIP
2203-005736	C1151,C1244,C1247	C-CERAMIC,CHIP
2203-005736	C2000,C2015,C2027	C-CERAMIC,CHIP
2203-005736	C2028,C2049,C2052	C-CERAMIC,CHIP
2203-005736	C2053,C2067,C2072	C-CERAMIC,CHIP
2203-005736	C2073,C2098,C2100	C-CERAMIC,CHIP
2203-005736	C2101,C2102,C2104	C-CERAMIC,CHIP
2203-005736	C2106,C2108,C2114	C-CERAMIC,CHIP
2203-005736	C2115,C2119,C2120	C-CERAMIC,CHIP
2203-005736	C2121,C2130,C2131	C-CERAMIC,CHIP
2203-005736	C2133,C2134,C3011	C-CERAMIC,CHIP
2203-005736	C3043,C3048,C3057	C-CERAMIC,CHIP
2203-005736	C3131,C5051,C5161	C-CERAMIC,CHIP
2203-005736	C6031,C7027,C7043	C-CERAMIC,CHIP
2203-005736	C7048,L2052,L2057	C-CERAMIC,CHIP
2203-005736	L3005,L3027,R1000	C-CERAMIC,CHIP
2203-005777	C2059,C2062,C2066	C-CERAMIC,CHIP
2203-005777	C2094,L1008,L2003	C-CERAMIC,CHIP
2203-005777	L2030	C-CERAMIC,CHIP
2203-005789	C1045,C2001,C2024	C-CERAMIC,CHIP
2203-005789	C2034,C2035,C2036	C-CERAMIC,CHIP
2203-005789	C2044,C2090,C2248	C-CERAMIC,CHIP
2203-005789	C2296,C3050,L1009	C-CERAMIC,CHIP
2203-005789	L1011,L2014	C-CERAMIC,CHIP
2203-005792	C1064,C1065,C2013	C-CERAMIC,CHIP
2203-005792	C2112,C5114,L2008	C-CERAMIC,CHIP
2203-005806	C2003,C2007,C2021	C-CERAMIC,CHIP
2203-005806	C2103	C-CERAMIC,CHIP
2203-006048	C6009	C-CERAMIC,CHIP
2203-006120	C6022	C-CERAMIC,CHIP
2203-006187	L1023	C-CERAMIC,CHIP
2203-006194	C2132,C5123,C5160	C-CERAMIC,CHIP
2203-006194	C6020,C6023	C-CERAMIC,CHIP
2203-006305	C2095,C2096,C2099	C-CERAMIC,CHIP
2203-006305	C3012,C3037,C3045	C-CERAMIC,CHIP
2203-006305	C3137,L2009,L2046	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006318	C2031,C5115	C-CERAMIC,CHIP
2203-006399	C4001,C4012,C4016	C-CERAMIC,CHIP
2203-006399	C4021,C4022,C4025	C-CERAMIC,CHIP
2203-006399	C4062,C4071,C7004	C-CERAMIC,CHIP
2203-006399	C7005	C-CERAMIC,CHIP
2203-006400	C1000,C1073,C1077	C-CERAMIC,CHIP
2203-006400	C2016,C2215,C2222	C-CERAMIC,CHIP
2203-006400	C3007,C4027,C4070	C-CERAMIC,CHIP
2203-006410	C2026,C2055,C2088	C-CERAMIC,CHIP
2203-006423	C2011,C2283,C3004	C-CERAMIC,CHIP
2203-006423	C3006,C3013,C3015	C-CERAMIC,CHIP
2203-006423	C3018,C4068,C4069	C-CERAMIC,CHIP
2203-006423	C5076,C5100,C5104	C-CERAMIC,CHIP
2203-006423	C5113,C5125,C5157	C-CERAMIC,CHIP
2203-006423	C5158,C6011,C6012	C-CERAMIC,CHIP
2203-006423	C7025	C-CERAMIC,CHIP
2203-006556	C2010,C2018,C2038	C-CERAMIC,CHIP
2203-006556	C2039,C2058,C5130	C-CERAMIC,CHIP
2203-006556	C5154,C5155,C6021	C-CERAMIC,CHIP
2203-006556	C6025,C6027	C-CERAMIC,CHIP
2203-006562	C2004,C4064,C4065	C-CERAMIC,CHIP
2203-006562	C5042,C5043,C5121	C-CERAMIC,CHIP
2203-006562	C6006,C6039,C7038	C-CERAMIC,CHIP
2203-006562	C7042	C-CERAMIC,CHIP
2203-006611	C2009,C5132,L1044	C-CERAMIC,CHIP
2203-006642	C2228	C-CERAMIC,CHIP
2203-006648	C6024	C-CERAMIC,CHIP
2203-006665	C2042,C3066	C-CERAMIC,CHIP
2203-006668	C2123,C2231,C4032	C-CERAMIC,CHIP
2203-006668	C5097,C5098	C-CERAMIC,CHIP
2203-006707	C3047,C3049,C3051	C-CERAMIC,CHIP
2203-006707	C3052,C3056	C-CERAMIC,CHIP
2203-006839	C2017,C5068,C5069	C-CERAMIC,CHIP
2203-006839	C5071,C7049,C7050	C-CERAMIC,CHIP
2203-006841	C5110,C5134	C-CERAMIC,CHIP
2203-006872	C7099	C-CERAMIC,CHIP
2203-006896	C6002,C6013	C-CERAMIC,CHIP
2203-006979	C2076,C2078,C2085	C-CERAMIC,CHIP
2203-006979	C2286,C2288,C2290	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006979	C2292,C2295,C3143	C-CERAMIC,CHIP
2203-006979	C3145,C6019,R6034	C-CERAMIC,CHIP
2203-007210	C3019,C3025,C3026	C-CERAMIC,CHIP
2203-007210	C5141,C5142,C6040	C-CERAMIC,CHIP
2203-007210	C6042	C-CERAMIC,CHIP
2203-007240	C5080,C5084,C5086	C-CERAMIC,CHIP
2203-007240	C5087,C5151,C5153	C-CERAMIC,CHIP
2203-007269	C7028,C7032,C7033	C-CERAMIC,CHIP
2203-007269	C7044,C7047	C-CERAMIC,CHIP
2203-007271	C2006,C2012,C5013	C-CERAMIC,CHIP
2203-007271	C5092,C5099,C5109	C-CERAMIC,CHIP
2203-007271	C5117	C-CERAMIC,CHIP
2203-007279	C2020,C5074,C7031	C-CERAMIC,CHIP
2203-007317	C3009,C3028,C4020	C-CERAMIC,CHIP
2203-007317	C4030,C5024,C5025	C-CERAMIC,CHIP
2203-007317	C7026,C7046,C7075	C-CERAMIC,CHIP
2203-007391	C2282,C3020,C6005	C-CERAMIC,CHIP
2203-007393	C1100,C5062,C5070	C-CERAMIC,CHIP
2203-007393	C5081,C5082,C5150	C-CERAMIC,CHIP
2203-007393	C7035	C-CERAMIC,CHIP
2203-007544	C6004	C-CERAMIC,CHIP
2203-007775	C5053	C-CERAMIC,CHIP
2203-007796	C1099,C2075,C2284	C-CERAMIC,CHIP
2203-007796	C2289,C2293,C3005	C-CERAMIC,CHIP
2203-007796	C3022,C3027,C4000	C-CERAMIC,CHIP
2203-007796	C4002,C4003,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4010,C4011,C4013	C-CERAMIC,CHIP
2203-007796	C4015,C4017,C4019	C-CERAMIC,CHIP
2203-007796	C4023,C4024,C4026	C-CERAMIC,CHIP
2203-007796	C4033,C4034,C4035	C-CERAMIC,CHIP
2203-007796	C4037,C4038,C4040	C-CERAMIC,CHIP
2203-007796	C4043,C4046,C4047	C-CERAMIC,CHIP
2203-007796	C4048,C4049,C4050	C-CERAMIC,CHIP
2203-007796	C4051,C4052,C4053	C-CERAMIC,CHIP
2203-007796	C4057,C4060,C4061	C-CERAMIC,CHIP
2203-007796	C4063,C5006,C5007	C-CERAMIC,CHIP
2203-007796	C5008,C5009,C5010	C-CERAMIC,CHIP
2203-007796	C5016,C5017,C5018	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C5019,C5020,C5022	C-CERAMIC,CHIP
2203-007796	C5028,C5034,C5035	C-CERAMIC,CHIP
2203-007796	C5036,C5037,C5038	C-CERAMIC,CHIP
2203-007796	C5040,C5073,C5079	C-CERAMIC,CHIP
2203-007796	C5088,C5089,C5090	C-CERAMIC,CHIP
2203-007796	C5091,C5118,C5144	C-CERAMIC,CHIP
2203-007796	C7006,C7011,C7013	C-CERAMIC,CHIP
2203-007796	C7014,C7015,C7017	C-CERAMIC,CHIP
2203-007796	C7018,C7019,C7021	C-CERAMIC,CHIP
2203-007796	C7023,C7040,C7041	C-CERAMIC,CHIP
2203-008094	C6028	C-CERAMIC,CHIP
2203-008097	C2019,C6029	C-CERAMIC,CHIP
2203-008161	C5004	C-CERAMIC,CHIP
2203-008242	C3031,C3135,C4028	C-CERAMIC,CHIP
2203-008242	C4041,C4044,C4056	C-CERAMIC,CHIP
2203-008242	C4059,C5039	C-CERAMIC,CHIP
2203-008529	C3030,C5000,C5001	C-CERAMIC,CHIP
2203-008529	C5059,C5063,C5064	C-CERAMIC,CHIP
2203-008529	C5065,C6008,C6043	C-CERAMIC,CHIP
2203-008572	C5054,C5136	C-CERAMIC,CHIP
2203-008654	C5149	C-CERAMIC,CHIP
2203-008860	C5083,C7010,C7016	C-CERAMIC,CHIP
2203-008860	C7020,C7022	C-CERAMIC,CHIP
2203-008876	C3008,C5106,C6036	C-CERAMIC,CHIP
2203-008876	C6038,C7039	C-CERAMIC,CHIP
2203-009444	C6026	C-CERAMIC,CHIP
2203-009551	C6032	C-CERAMIC,CHIP
2203-009733	C1098,C2077,C2287	C-CERAMIC,CHIP
2203-009733	C2291,C2294,C4036	C-CERAMIC,CHIP
2203-009733	C4042,C4055,C7001	C-CERAMIC,CHIP
2203-009733	C7045,C7074	C-CERAMIC,CHIP
2203-009736	C3032,C4014,C4018	C-CERAMIC,CHIP
2203-009736	C5023,C5112,C5143	C-CERAMIC,CHIP
2203-009736	C5152	C-CERAMIC,CHIP
2203-009858	C5041,C5066	C-CERAMIC,CHIP
2203-009917	C6003	C-CERAMIC,CHIP
2703-002309	L6008	INDUCTOR-SMD
2703-002649	C1062,L2007	INDUCTOR-SMD
2703-002858	L1027	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-002900	L5008	INDUCTOR-SMD
2703-002901	L1022,L1025	INDUCTOR-SMD
2703-002907	L2034,L3020	INDUCTOR-SMD
2703-002951	C1074	INDUCTOR-SMD
2703-002953	C1009,C2122,L1071	INDUCTOR-SMD
2703-002953	L5009	INDUCTOR-SMD
2703-002955	L1037	INDUCTOR-SMD
2703-002958	L1005,L1006,L1034	INDUCTOR-SMD
2703-002958	L1077	INDUCTOR-SMD
2703-002959	L1021,L1045,L1048	INDUCTOR-SMD
2703-002959	L3035,U7031	INDUCTOR-SMD
2703-002999	C1042	INDUCTOR-SMD
2703-003878	L6012	INDUCTOR-SMD
2703-003970	L1124	INDUCTOR-SMD
2703-004000	L2051	INDUCTOR-SMD
2703-004001	C1025	INDUCTOR-SMD
2703-004012	C1003,C1066,L2005	INDUCTOR-SMD
2703-004012	L2010,L2011,L2020	INDUCTOR-SMD
2703-004012	L2058	INDUCTOR-SMD
2703-004013	C2091,L2022,L2029	INDUCTOR-SMD
2703-004013	L2048,L2070,L2071	INDUCTOR-SMD
2703-004013	L3030	INDUCTOR-SMD
2703-004018	C1023,C2030,L1015	INDUCTOR-SMD
2703-004018	L1017,L1068,L2016	INDUCTOR-SMD
2703-004018	L2032,L3031,L3037	INDUCTOR-SMD
2703-004032	C1017,L1014,L1049	INDUCTOR-SMD
2703-004034	C2113,L1019,L1035	INDUCTOR-SMD
2703-004034	L3015	INDUCTOR-SMD
2703-004035	L1047	INDUCTOR-SMD
2703-004036	L1046,L2078	INDUCTOR-SMD
2703-004037	L1018	INDUCTOR-SMD
2703-004038	C1002,C1021,C1051	INDUCTOR-SMD
2703-004038	C1061,C2084,C2097	INDUCTOR-SMD
2703-004038	L1003,L1007,L1041	INDUCTOR-SMD
2703-004038	L2043,L2053,L3029	INDUCTOR-SMD
2703-004286	L1004,L2002,L2021	INDUCTOR-SMD
2703-004286	L2024,L2028,L2044	INDUCTOR-SMD
2703-004286	L2050,L2056,L2065	INDUCTOR-SMD
2703-004286	L3033	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004288	L3032	INDUCTOR-SMD
2703-004289	L3016	INDUCTOR-SMD
2703-004301	C2029,C2087,C2129	INDUCTOR-SMD
2703-004328	L2006,L2012,L2017	INDUCTOR-SMD
2703-004328	L2036,L2041,L2049	INDUCTOR-SMD
2703-004328	L2054,L2063	INDUCTOR-SMD
2703-004363	C2014	INDUCTOR-SMD
2703-004367	L1020	INDUCTOR-SMD
2703-004369	L3013	INDUCTOR-SMD
2703-004763	L1001,L1028,L1032	INDUCTOR-SMD
2703-004763	L1043	INDUCTOR-SMD
2703-004764	C1071	INDUCTOR-SMD
2703-004853	C1030,L1002,L2074	INDUCTOR-SMD
2703-004901	L5002,L5003,L5004	INDUCTOR-SMD
2703-004901	L5005,L5006	INDUCTOR-SMD
2703-004911	L1038	INDUCTOR-SMD
2703-005066	L1033	INDUCTOR-SMD
2703-005085	C1008,C2041,C2046	INDUCTOR-SMD
2703-005085	C3041,L1029,L1030	INDUCTOR-SMD
2703-005085	L2001,L2023,L2047	INDUCTOR-SMD
2703-005085	L2077	INDUCTOR-SMD
2703-005087	C2093,C2136,L1012	INDUCTOR-SMD
2703-005087	L2000,L2045,L2066	INDUCTOR-SMD
2703-005087	L2067	INDUCTOR-SMD
2703-005109	L5011	INDUCTOR-SMD
2703-005117	L7007,L7008	INDUCTOR-SMD
2703-005118	L7006	INDUCTOR-SMD
2703-005200	L3006	INDUCTOR-SMD
2703-005296	C2022,C2137,L1024	INDUCTOR-SMD
2703-005505	L6001	INDUCTOR-SMD
2801-005487	OSC3000	CRYSTAL-UNIT
2801-005496	OSC5000	CRYSTAL-UNIT
2805-001106	OSC3001	OSCILLATOR
2809-001419	TCX2000	OSCILLATOR-VCTCXO
2901-001798	F7005,F7006,F7007	FILTER-EMI SMD
2901-001798	F7008,F7009	FILTER-EMI SMD
2904-002143	F2002	FILTER-SAW
2904-002257	F2007	FILTER-SAW
2904-002266	F1002	FILTER-SAW

5. MAIN Electrical Parts List

2904-002326	F2008	FILTER-SAW
2904-002339	F2006	FILTER-SAW
2904-002349	F2005	FILTER-SAW
2904-002350	F2003	FILTER-SAW
2904-002355	F3003,F3004	FILTER-SAW
2904-002365	F2000	FILTER-SAW
2904-002390	F3000	FILTER-SAW
2910-000364	F1007	FILTER
2910-000401	F2001	FILTER
2910-000402	U1007	FILTER
2911-000435	U2005	FILTER
2911-000447	U1003	FILTER
3301-001438	L3036	CORE-FERRITE BEAD
3301-001778	R1028	CORE-FERRITE BEAD
3301-001885	L6000,L6014,L6016	CORE-FERRITE BEAD
3301-002078	L6006,L6007,L6009	CORE-FERRITE BEAD
3301-002078	L6010,L6013,L7003	CORE-FERRITE BEAD
3301-002078	L7012,R6018	CORE-FERRITE BEAD
3301-002122	L1031,L1230,L2069	CORE-FERRITE BEAD
3301-002122	L6002,L6004	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7013	CORE-FERRITE BEAD
3301-002223	L7014	CORE-FERRITE BEAD
3301-002236	L5015,L6003,L6005	CORE-FERRITE BEAD
3301-002236	L6015	CORE-FERRITE BEAD
3301-002237	L1000,L1042,L2073	CORE-FERRITE BEAD
3301-002237	L3000	CORE-FERRITE BEAD
3301-002238	L2039,L2042,L3007	CORE-FERRITE BEAD
3301-002238	L3009	CORE-FERRITE BEAD
3301-002240	L2059,L2061	CORE-FERRITE BEAD
3301-002241	R7005	CORE-FERRITE BEAD
3301-002254	L5000,L5007	CORE-FERRITE BEAD
3301-002287	L5014	CORE-FERRITE BEAD
3301-002304	R7013	CORE-FERRITE BEAD
3301-002312	L2037,L2040,L2060	CORE-FERRITE BEAD
3301-002312	L2062,L4000,L7005	CORE-FERRITE BEAD
3301-002312	L7009,L7010	CORE-FERRITE BEAD
3301-002335	L6011	CORE-FERRITE BEAD
3705-001708	CON1000,CON1006	CONNECTOR-COAXIAL
3709-001880	CN5000	CONNECTOR-CARD EDGE

5. MAIN Electrical Parts List

3709-001891	CN5001	CONNECTOR-CARD EDGE
3711-007107	HEA7001	CONNECTOR-HEADER
3711-007810	HEA6000	CONNECTOR-HEADER
3711-008182	HEA7000	CONNECTOR-HEADER
3711-008508	HEA7002	CONNECTOR-HEADER
3711-008847	HDC5001	CONNECTOR-HEADER
3712-001621	ANT6004,ANT6005	CONNECTOR
3712-001621	ANT6006,ANT6007	CONNECTOR
3712-001621	ANT6008,ANT6009	CONNECTOR
3712-001621	ANT6010,ANT6011	CONNECTOR
3712-001621	ANT6012,CON5001	CONNECTOR
3712-001621	CON5002,CON5003	CONNECTOR
3712-001634	ANT5004,ANT5006	CONNECTOR
3712-001666	ANT6002,ANT6003	CONNECTOR
3712-001694	ANT1010,ANT1011	CONNECTOR
3712-001694	ANT1012,ANT1015	CONNECTOR
3712-001694	ANT1016,ANT2002	CONNECTOR
3712-001694	ANT5003,ANT5007	CONNECTOR
3712-001694	ANT6000,ANT6001	CONNECTOR
3712-001749	ANT1002,ANT1003	CONNECTOR
3712-001749	ANT1004,ANT1005	CONNECTOR
3712-001749	ANT1007,ANT1008	CONNECTOR
3712-001749	ANT1009,ANT2001	CONNECTOR
3712-001749	ANT2004,ANT2006	CONNECTOR
3712-001749	ANT2007,ANT2008	CONNECTOR
3712-001749	ANT2010,ANT3005	CONNECTOR
3712-001749	ANT3006	CONNECTOR
3712-001800	ANT1000,ANT1013	CONNECTOR
3712-001800	ANT1018,ANT1020	CONNECTOR
3722-003954	IFC5000	JACK-PHONE
4709-002196	F2009	RF-MODULE
4709-002351	F3001	RF-MODULE
4709-002464	F1000	RF-MODULE
4709-002484	F2004	RF-MODULE
4709-002589	F1001,F1004	RF-MODULE
GH61-04484A	SUS7000	SHIELD CAN
GH61-08266A	SUS7001	SHIELD CAN
GH62-00044A	CN7000,CN7001	SHIELD CAN
GH63-14633A	SC7003	SHIELD CAN

5. MAIN Electrical Parts List

GH63-15417A	SC7006	SHIELD CAN
GH63-15418A	SC7007	SHIELD CAN
GH63-15419A	SC7008	SHIELD CAN
GH63-15420A	SC7004	SHIELD CAN
GH63-15421A	SC7002	SHIELD CAN
GH63-15422A	SC7005	SHIELD CAN
GH02-16501A	SC7004SP	;TAPE

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.